

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730	
Weight per litre		0.70		Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20									26	28	30	32	35	37	39			
30					26	29	32	36	39	42	45	49	52	55	58			
40			26	30	35	39	43	48	52	56	60	65	69	73	78			
50		27	32	38	43	49	54	59	65	70	76	81	86	92	97			
60	26	32	39	45	52	58	65	71	78	84	91	97	104	110	117			
70	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136			
80	35	43	52	60	69	78	86	95	104	112	121	130	138	147	156			
90	39	49	58	68	78	87	97	107	117	126	136	146	156	165	175			
100	43	54	65	76	86	97	108	119	130	140	151	162	173	184	194			
110	48	59	71	83	95	107	119	131	143	154	166	178	190	202	214			
120	52	65	78	91	104	117	130	143	156	168	181	194	207	220	233			
130	56	70	84	98	112	126	140	154	168	183	197	211	225	239	253			
140	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272			
150	65	81	97	113	130	146	162	178	194	211	227	243	259	275	292			
160	69	86	104	121	138	156	173	190	207	225	242	259	276	294				
170	73	92	110	129	147	165	184	202	220	239	257	275	294					
180	78	97	117	136	156	175	194	214	233	253	272	292						
190	82	103	123	144	164	185	205	226	246	267	287	308						
200	86	108	130	151	173	194	216	238	259	281	302							
210	91	113	136	159	181	204	227	249	272	295								
220	95	119	143	166	190	214	238	261	285	309								
230	99	124	149	174	199	224	248	273	298									
240	104	130	156	181	207	233	259	285										
250	108	135	162	189	216	243	270	297										
260	112	140	168	197	225	253	281	309										
270	117	146	175	204	233	262	292											
280	121	151	181	212	242	272	302											
290	125	157	188	219	251	282												
300	130	162	194	227	259	292												
320	138	173	207	242	276													
340	147	184	220	257	294													
360	156	194	233	272														
380	164	205	246	287														
400	173	216	259	302														
425	184	230	275															
450	194	243	292															
475	205	257	308															
500	216	270																
525	227	284																
550	238	297																
575	248																	
600	259																	

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730	
Weight per litre		0.75		Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20																		
30																		
40																		
50		25	30	35	40	45	50	55	60	66	71	76	81	86	91			
60		30	36	42	48	54	60	67	73	79	85	91	97	103	109			
70	28	35	42	49	56	64	71	78	85	92	99	106	113	120	127			
80	32	40	48	56	65	73	81	89	97	105	113	121	129	137	145			
90	36	45	54	64	73	82	91	100	109	118	127	136	145	154	163			
100	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181			
110	44	55	67	78	89	100	111	122	133	144	155	166	177	188	200			
120	48	60	73	85	97	109	121	133	145	157	169	181	194	206	218			
130	52	66	79	92	105	118	131	144	157	170	183	197	210	223	236			
140	56	71	85	99	113	127	141	155	169	183	198	212	226	240	254			
150	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272			
160	65	81	97	113	129	145	161	177	194	210	226	242	258	274	290			
170	69	86	103	120	137	154	171	188	206	223	240	257	274	291	308			
180	73	91	109	127	145	163	181	200	218	236	254	272	290	308				
190	77	96	115	134	153	172	192	211	230	249	268	287	306					
200	81	101	121	141	161	181	202	222	242	262	282	302						
210	85	106	127	148	169	191	212	233	254	275	296							
220	89	111	133	155	177	200	222	244	266	288								
230	93	116	139	162	185	209	232	255	278	301								
240	97	121	145	169	194	218	242	266	290									
250	101	126	151	176	202	227	252	277	302									
260	105	131	157	183	210	236	262	288										
270	109	136	163	191	218	245	272	299										
280	113	141	169	198	226	254	282											
290	117	146	175	205	234	263	292											
300	121	151	181	212	242	272	302											
320	129	161	194	226	258	290												
340	137	171	206	240	274	308												
360	145	181	218	254	290													
380	153	192	230	268	306													
400	161	202	242	282														
425	171	214	257	300														
450	181	227	272															
475	192	239	287															
500	202	252	302															
525	212	265																
550	222	277																
575	232	290																
600	242	302																

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730	
Weight per litre		0.80		Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20											26	28	30	32	34			
30						26	28	31	34	37	40	43	45	48	51			
40				26	30	34	38	42	45	49	53	57	60	64	68			
50			28	33	38	43	47	52	57	61	66	71	76	80	85			
60		28	34	40	45	51	57	62	68	74	79	85	91	96	102			
70	26	33	40	46	53	60	66	73	79	86	93	99	106	112	119			
80	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136			
90	34	43	51	60	68	77	85	94	102	111	119	128	136	145	153			
100	38	47	57	66	76	85	95	104	113	123	132	142	151	161	170			
110	42	52	62	73	83	94	104	114	125	135	146	156	166	177	187			
120	45	57	68	79	91	102	113	125	136	147	159	170	181	193	204			
130	49	61	74	86	98	111	123	135	147	160	172	184	197	209	221			
140	53	66	79	93	106	119	132	146	159	172	185	198	212	225	238			
150	57	71	85	99	113	128	142	156	170	184	198	213	227	241	255			
160	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272			
170	64	80	96	112	129	145	161	177	193	209	225	241	257	273	289			
180	68	85	102	119	136	153	170	187	204	221	238	255	272	289	306			
190	72	90	108	126	144	162	180	198	215	233	251	269	287	305				
200	76	95	113	132	151	170	189	208	227	246	265	284	302					
210	79	99	119	139	159	179	198	218	238	258	278	298						
220	83	104	125	146	166	187	208	229	249	270	291							
230	87	109	130	152	174	196	217	239	261	283	304							
240	91	113	136	159	181	204	227	249	272	295								
250	95	118	142	165	189	213	236	260	284	307								
260	98	123	147	172	197	221	246	270	295									
270	102	128	153	179	204	230	255	281	306									
280	106	132	159	185	212	238	265	291										
290	110	137	164	192	219	247	274	301										
300	113	142	170	198	227	255	284											
320	121	151	181	212	242	272	302											
340	129	161	193	225	257	289												
360	136	170	204	238	272	306												
380	144	180	215	251	287													
400	151	189	227	265	302													
425	161	201	241	281														
450	170	213	255	298														
475	180	224	269															
500	189	236	284															
525	198	248	298															
550	208	260																
575	217	272																
600	227	284																

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730	
Weight per litre		0.85		Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20																		
30																27	28	
40																30	32	
50																35	37	
60																40	43	
70																45	48	
80																50	53	
90																55	57	
100																60	64	
110																65	68	
120																70	76	
130																75	80	
140																80	85	
150																85	91	
160																90	96	
170																95	100	
180																100	106	
190																105	112	
200																110	117	
210																115	122	
220																120	128	
230																125	133	
240																130	139	
250																135	144	
260																140	150	
270																145	155	
280																150	160	
290																155	165	
300																160	170	
320																165	176	
340																170	181	
360																175	187	
380																180	192	
400																185	204	
425																190	216	
450																195	228	
475																200	240	
500																205	252	
525																210	264	
550																215	276	
575																220	288	
600																225	300	

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART KG. PER H														gb006 730	
Weight per litre		0.90														Figures in body of chart = mm of door opening	
Width		8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate					26	30	34	37	41	45	49	52	56	60	63	67	
100					29	33	37	41	45	49	53	57	62	66	70	74	
110				27	31	36	40	45	49	54	58	63	67	72	76	81	
120			26	31	37	42	47	52	57	63	68	73	78	84	89	94	
130			28	34	39	45	50	56	62	67	73	78	84	90	95	101	
140			30	36	42	48	54	60	66	72	78	84	90	96	102	108	
150	25	32	38	44	51	57	63	70	76	83	89	95	102	108	114	121	
160	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121	128	
170	28	35	43	50	57	64	71	78	85	92	99	106	113	121	128	134	
180	30	37	45	52	60	67	75	82	90	97	105	112	119	127	134	141	
190	31	39	47	55	63	71	78	86	94	102	110	118	125	133	141	148	
200	33	41	49	57	66	74	82	90	99	107	115	123	131	140	148	155	
210	34	43	52	60	69	77	86	94	103	112	120	129	137	146	155	161	
220	36	45	54	63	72	81	90	99	108	116	125	134	143	152	161	168	
230	37	47	56	65	75	84	93	103	112	121	131	140	149	159	168	175	
240	39	49	58	68	78	87	97	107	116	126	136	146	155	165	175	181	
250	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181	188	
260	42	52	63	73	84	94	105	115	125	136	146	157	167	178	188	195	
270	43	54	65	76	87	97	108	119	130	141	152	162	173	184	195	202	
280	45	56	67	78	90	101	112	123	134	146	157	168	179	190	202	215	
290	48	60	72	84	96	108	119	131	143	155	167	179	191	203	215	228	
300	51	63	76	89	102	114	127	140	152	165	178	190	203	216	228	242	
320	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242	255	
340	57	71	85	99	113	128	142	156	170	184	199	213	227	241	255	269	
360	60	75	90	105	119	134	149	164	179	194	209	224	239	254	269	286	
380	63	79	95	111	127	143	159	175	190	206	222	238	254	270	286	302	
400	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302		
425	71	89	106	124	142	160	177	195	213	231	248	266	284	301			
450	75	93	112	131	149	168	187	205	224	243	261	280	299				
475	78	98	118	137	157	176	196	216	235	255	274	294					
500	82	103	123	144	164	185	205	226	246	267	287	308					
525	86	107	129	150	172	193	215	236	258	279	301						
550	90	112	134	157	179	202	224	246	269	291							
575	97	121	146	170	194	218	243	267	291								
600	105	131	157	183	209	235	261	287									
650	112	140	168	196	224	252	280	308									
700	119	149	179	209	239	269	299										
750	127	159	190	222	254	286											
800	134	168	202	235	269	302											
850	142	177	213	248	284												
900	149	187	224	261	299												

Gear Box...Med. Gear		RATE CHART KG. PER H														gb006 730	
Weight per litre		0.95														Figures in body of chart = mm of door opening	
Width		8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate										28	32	35	39	42	46	50	
100										27	31	35	39	43	47	51	
110										30	34	38	42	47	51	55	
120				25	30	34	38	42	47	51	55	59	64	68	72	76	
130				28	32	37	41	46	51	55	60	64	69	74	78	83	
140				30	35	40	45	50	54	59	64	69	74	79	84	89	
150			27	32	37	42	48	53	58	64	69	74	80	85	90	95	
160			28	34	40	45	51	57	62	68	74	79	85	91	96	102	
170			30	36	42	48	54	60	66	72	78	84	90	96	102	108	
180	25	32	38	45	51	57	64	70	76	83	89	95	102	108	114	121	
190	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121	128	
200	28	35	42	50	57	64	71	78	85	92	99	106	113	120	127	134	
210	30	37	45	52	59	67	74	82	89	97	104	111	119	126	134	141	
220	31	39	47	54	62	70	78	86	93	101	109	117	124	132	140	148	
230	33	41	49	57	65	73	81	89	98	106	114	122	130	138	146	155	
240	34	42	51	59	68	76	85	93	102	110	119	127	136	144	153	161	
250	35	44	53	62	71	80	88	97	106	115	124	133	141	150	159	168	
260	37	46	55	64	74	83	92	101	110	120	129	138	147	156	166	175	
270	38	48	57	67	76	86	95	105	115	124	134	143	153	162	172	181	
280	40	50	59	69	79	89	99	109	119	129	139	149	158	168	178	188	
290	41	51	62	72	82	92	103	113	123	133	144	154	164	174	185	195	
300	42	53	64	74	85	95	106	117	127	138	149	159	170	180	191	202	
320	45	57	68	79	91	102	113	124	136	147	158	170	181	192	204	216	
340	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216	229	
360	51	64	76	89	102	115	127	140	153	166	178	191	204	216	229	242	
380	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242	255	
400	57	71	85	99	113	127	141	156	170	184	198	212	226	241	255	269	
425	60	75	90	105	120	135	150	165	180	195	210	225	241	256	271	286	
450	64	80	95	111	127	143	159	175	191	207	223	239	255	271	286	302	
475	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302		
500	71	88	106	124	141	159	177	195	212	230	248	265	283	301			
525	74	93	111	130	149	167	186	204	223	241	260	279	297				
550	78	97	117	136	156	175	195	214	233	253	272	292					
575	81	102	122	142	163	183	203	224	244	264	285	305					
600	85	106	127	149	170	191	212	233	255	276	297						
650	92	115	138	161	184	207	230	253	276	299							
700	99	124	149	173	198	223	248	272	297								
750	106	133	159	186	212	239	265	292									
800	113	141	170	198	226	255	283										
850	120	150	180	210	241	271	301										
900	127	159	191	22													

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730	
Weight per litre				0.90														
				Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20												25	27	29	30			
30							25	28	30	33	35	38	40	43	45			
40					27	30	34	37	40	44	47	50	54	57	60			
50			25	29	34	38	42	46	50	55	59	63	67	71	76			
60		25	30	35	40	45	50	55	60	66	71	76	81	86	91			
70		29	35	41	47	53	59	65	71	76	82	88	94	100	106			
80	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121			
90	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136			
100	34	42	50	59	67	76	84	92	101	109	118	126	134	143	151			
110	37	46	55	65	74	83	92	102	111	120	129	139	148	157	166			
120	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181			
130	44	55	66	76	87	98	109	120	131	142	153	164	175	186	197			
140	47	59	71	82	94	106	118	129	141	153	165	176	188	200	212			
150	50	63	76	88	101	113	126	139	151	164	176	189	202	214	227			
160	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242			
170	57	71	86	100	114	129	143	157	171	186	200	214	228	243	257			
180	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272			
190	64	80	96	112	128	144	160	176	192	207	223	239	255	271	287			
200	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302			
210	71	88	106	123	141	159	176	194	212	229	247	265	282	300				
220	74	92	111	129	148	166	185	203	222	240	259	277	296					
230	77	97	116	135	155	174	193	213	232	251	270	290	309					
240	81	101	121	141	161	181	202	222	242	262	282	302						
250	84	105	126	147	168	189	210	231	252	273	294							
260	87	109	131	153	175	197	218	240	262	284	306							
270	91	113	136	159	181	204	227	249	272	295								
280	94	118	141	165	188	212	235	259	282	306								
290	97	122	146	171	195	219	244	268	292									
300	101	126	151	176	202	227	252	277	302									
320	108	134	161	188	215	242	269	296										
340	114	143	171	200	228	257	286											
360	121	151	181	212	242	272	302											
380	128	160	192	223	255	287												
400	134	168	202	235	269	302												
425	143	179	214	250	286													
450	151	189	227	265	302													
475	160	200	239	279														
500	168	210	252	294														
525	176	221	265	309														
550	185	231	277															
575	193	242	290															
600	202	252	302															

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730	
Weight per litre				0.95														
				Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20																25	27	
30																26	29	
40																26	29	
50										25	29	32	35	38	41	45	48	
60										28	33	36	40	44	48	52	56	
70										29	33	38	43	48	53	57	62	
80	25	32	38	45	51	57	64	70	76	83	89	95	102	108	115	122	129	
90	29	36	43	50	57	64	72	79	86	93	100	107	115	122	129	136	143	
100	32	40	48	56	64	72	80	88	95	103	111	119	127	135	143	151	158	
110	35	44	53	61	70	79	88	96	105	114	123	131	140	149	158	166	175	
120	38	48	57	67	76	86	95	105	115	124	134	143	153	162	172	181	191	
130	41	52	62	72	83	93	103	114	124	134	145	155	166	176	186	196	206	
140	45	56	67	78	89	100	111	123	134	145	156	167	178	189	200	211	221	
150	48	60	72	84	95	107	119	131	143	155	167	179	191	203	215	227	239	
160	51	64	76	89	102	115	127	140	153	166	178	191	204	216	229	241	254	
170	54	68	81	95	108	122	135	149	162	176	189	203	216	230	244	257	271	
180	57	72	86	100	115	129	143	158	172	186	201	215	229	244	258	272	286	
190	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272	287	302	
200	64	80	95	111	127	143	159	175	191	207	223	239	255	271	286	302	317	
210	67	84	100	117	134	150	167	184	201	217	234	251	267	284	301	317	333	
220	70	88	105	123	140	158	175	193	210	228	245	263	280	298	315	333	350	
230	73	92	110	128	146	165	183	201	220	238	256	275	293	311	330	348	366	
240	76	95	115	134	153	172	191	210	229	248	267	286	306	325	344	363	382	
250	80	99	119	139	159	179	199	219	239	259	279	298	318	337	356	375	394	
260	83	103	124	145	166	186	207	228	248	269	290	310	330	350	370	390	410	
270	86	107	129	150	172	193	215	236	258	279	301	322	343	364	385	406	427	
280	89	111	134	156	178	201	223	245	267	290	311	332	353	374	395	416	437	
290	92	115	138	162	185	208	231	254	277	300	321	342	363	384	405	426	447	
300	95	119	143	167	191	215	239	263	286	309	332	355	378	401	424	447	470	
320	102	127	153	178	204	229	255	280	306	331	356	381	406	431	456	481	506	
340	108	135	162	189	216	244	271	298	325	352	379	406	433	460	487	514	541	
360	115	143	172	201	229	258	286	314	342	370	398	426	454	482	510	538	566	
380	121	151	181	212	242	272	302	331	360	389	418	447	476	505	534	563	592	
400	127	159	191	223	255	286	317	348	379	409	439	469	499	529	559	589	619	
425	135	169	203	237	271	304	337	370	403	436	469	502	535	568	601	634		

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box		LOW		RATE CHART KG. PER HA.													gb006 730	
Weight per litre		1.00		Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20															26	27		
30									27	29	32	34	36	39	41			
40						27	30	33	36	39	42	45	48	51	54			
50					26	30	34	38	42	45	49	53	57	60	64	68		
60			27	32	36	41	45	50	54	59	64	68	73	77	82			
70		26	32	37	42	48	53	58	64	69	74	79	85	90	95			
80		30	36	42	48	54	60	67	73	79	85	91	97	103	109			
90	27	34	41	48	54	61	68	75	82	88	95	102	109	116	122			
100	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136			
110	33	42	50	58	67	75	83	91	100	108	116	125	133	141	150			
120	36	45	54	64	73	82	91	100	109	118	127	136	145	154	163			
130	39	49	59	69	79	88	98	108	118	128	138	147	157	167	177			
140	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191			
150	45	57	68	79	91	102	113	125	136	147	159	170	181	193	204			
160	48	60	73	85	97	109	121	133	145	157	169	181	194	206	218			
170	51	64	77	90	103	116	129	141	154	167	180	193	206	218	231			
180	54	68	82	95	109	122	136	150	163	177	191	204	218	231	245			
190	57	72	86	101	115	129	144	158	172	187	201	215	230	244	259			
200	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272			
210	64	79	95	111	127	143	159	175	191	206	222	238	254	270	286			
220	67	83	100	116	133	150	166	183	200	216	233	249	266	283	299			
230	70	87	104	122	139	156	174	191	209	226	243	261	278	296				
240	73	91	109	127	145	163	181	200	218	236	254	272	290	308				
250	76	95	113	132	151	170	189	208	227	246	265	284	302					
260	79	98	118	138	157	177	197	216	236	256	275	295						
270	82	102	122	143	163	184	204	225	245	265	286	306						
280	85	106	127	148	169	191	212	233	254	275	296							
290	88	110	132	153	175	197	219	241	263	285	307							
300	91	113	136	159	181	204	227	249	272	295								
320	97	121	145	169	194	218	242	266	290									
340	103	129	154	180	206	231	257	283	308									
360	109	136	163	191	218	245	272	299										
380	115	144	172	201	230	259	287											
400	121	151	181	212	242	272	302											
425	129	161	193	225	257	289												
450	136	170	204	238	272	306												
475	144	180	215	251	287													
500	151	189	227	265	302													
525	159	198	238	278														
550	166	208	249	291														
575	174	217	261	304														
600	181	227	272															

Gear Box		LOW		RATE CHART KG. PER HA.													gb006 730	
Weight per litre		1.05		Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20																26		
30																26	28	
40																30	32	
50																35	37	
60																43	47	
70																52	56	
80																60	65	
90																69	75	
100	26	32	39	45	52	58	65	71	78	84	91	97	104	110	117	124	130	
110	29	36	43	50	58	65	72	79	86	94	101	108	115	122	130	137	144	
120	32	40	48	55	63	71	79	87	95	103	111	119	127	135	143	151	159	
130	35	43	52	60	69	78	86	95	104	112	121	130	138	147	156	164	172	
140	37	47	56	66	75	84	94	103	112	122	131	140	150	159	168	177	186	
150	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181	191	200	
160	43	54	65	76	86	97	108	119	130	140	151	162	173	184	194	204	214	
170	46	58	69	81	92	104	115	127	138	150	161	173	184	196	207	217	227	
180	49	61	73	86	98	110	122	135	147	159	171	184	196	208	220	231	242	
190	52	65	78	91	104	117	130	143	156	168	181	194	207	220	233	246	259	
200	55	68	82	96	109	123	137	150	164	178	192	205	219	233	246	260	274	
210	58	72	86	101	115	130	144	158	173	187	202	216	230	245	259	273	287	
220	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272	286	301	
230	63	79	95	111	127	143	158	174	190	206	222	238	253	269	285	300	315	
240	66	83	99	116	132	149	166	182	199	215	232	248	265	282	298	314	330	
250	69	86	104	121	138	156	173	190	207	225	242	259	276	294	311	328	345	
260	72	90	108	126	144	162	180	198	216	234	252	270	288	306	324	342	360	
270	75	94	112	131	150	168	187	206	225	243	262	281	300					
280	78	97	117	136	156	175	194	214	233	253	272	292						
290	81	101	121	141	161	181	202	222	242	262	282	302						
300	84	104	125	146	167	188	209	230	251	271	292							
320	86	108	130	151	173	194	216	238	259	281	302							
340	92	115	138	161	184	207	230	253	276	300								
360	98	122	147	171	196	220	245	269	294									
380	104	130	156	181	207	233	259	285										
400	109	137	164	192	219	246	274	301										
425	115	144	173	202	230	259	288											
450	122	153	184	214	245	275	306											
475	130	162	194	227	259	292												
500	137	171	205	239	274	308												
525	144	180	216	252	288													
550	151	189	227	265	302													
575	158	198	238	277														
600	166	207	248	290														
600	173	216	259	302														

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box		LOW		RATE CHART KG. PER HA.													gb006 730	
Weight per litre				Figures in body of chart = mm of door opening														
		1.10																
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20																		
30										27	29	31	33	35	37			
40							27	30	33	36	38	41	44	47	49			
50					27	31	34	38	41	45	48	52	55	58	62			
60				29	33	37	41	45	49	54	58	62	66	70	74			
70			29	34	38	43	48	53	58	63	67	72	77	82	87			
80		27	33	38	44	49	55	60	66	71	77	82	88	93	99			
90		31	37	43	49	56	62	68	74	80	87	93	99	105	111			
100	27	34	41	48	55	62	69	76	82	89	96	103	110	117	124			
110	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136			
120	33	41	49	58	66	74	82	91	99	107	115	124	132	140	148			
130	36	45	54	63	71	80	89	98	107	116	125	134	143	152	161			
140	38	48	58	67	77	87	96	106	115	125	135	144	154	164	173			
150	41	52	62	72	82	93	103	113	124	134	144	155	165	175	186			
160	44	55	66	77	88	99	110	121	132	143	154	165	176	187	198			
170	47	58	70	82	93	105	117	129	140	152	164	175	187	199	210			
180	49	62	74	87	99	111	124	136	148	161	173	186	198	210	223			
190	52	65	78	91	104	118	131	144	157	170	183	196	209	222	235			
200	55	69	82	96	110	124	137	151	165	179	192	206	220	234	247			
210	58	72	87	101	115	130	144	159	173	188	202	216	231	245	260			
220	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272			
230	63	79	95	111	126	142	158	174	190	205	221	237	253	269	285			
240	66	82	99	115	132	148	165	181	198	214	231	247	264	280	297			
250	69	86	103	120	137	155	172	189	206	223	241	258	275	292	309			
260	71	89	107	125	143	161	179	197	214	232	250	268	286	304				
270	74	93	111	130	148	167	186	204	223	241	260	278	297					
280	77	96	115	135	154	173	192	212	231	250	269	289	308					
290	80	100	120	140	159	179	199	219	239	259	279	299						
300	82	103	124	144	165	186	206	227	247	268	289	309						
320	88	110	132	154	176	198	220	242	264	286	308							
340	93	117	140	164	187	210	234	257	280	304								
360	99	124	148	173	198	223	247	272	297									
380	104	131	157	183	209	235	261	287										
400	110	137	165	192	220	247	275	302										
425	117	146	175	204	234	263	292											
450	124	155	186	216	247	278	309											
475	131	163	196	229	261	294												
500	137	172	206	241	275	309												
525	144	180	216	253	289													
550	151	189	227	265	302													
575	158	198	237	277														
600	165	206	247	289														

Gear Box		LOW		RATE CHART KG. PER HA.													gb006 730	
Weight per litre				Figures in body of chart = mm of door opening														
		1.15																
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20																		
30																26	28	
40																32	34	
50										26	29	32	34	37	39	42	45	
60										26	30	33	36	39	43	46	49	
70										28	32	35	39	43	47	51	55	
80			28	32	37	41	46	51	55	60	64	69	74	78	83	87	91	
90		26	32	37	42	47	53	58	63	68	74	79	84	89	95	101	106	
100	26	33	39	46	53	59	66	72	79	85	92	99	105	112	118	125	130	
110	29	36	43	51	58	65	72	80	87	94	101	108	116	123	130	136	142	
120	32	39	47	55	63	71	79	87	95	103	111	120	128	137	145	154	162	
130	34	43	51	60	68	77	85	94	103	111	120	128	137	145	154	163	172	
140	37	46	55	64	74	83	92	101	110	120	129	138	147	156	166	175	184	
150	39	49	59	69	79	89	99	108	118	128	138	148	158	168	177	187	197	
160	42	53	63	74	84	95	105	116	126	137	147	158	168	179	189	199	209	
170	45	56	67	78	89	101	112	123	134	145	156	168	179	190	201	211	221	
180	47	59	71	83	95	106	118	130	142	154	166	177	189	201	213	224	235	
190	50	62	75	87	100	112	125	137	150	162	175	187	200	212	225	237	249	
200	53	66	79	92	105	118	131	145	158	171	184	197	210	224	237	250	263	
210	55	69	83	97	110	124	138	152	166	179	193	207	221	235	248	261	274	
220	58	72	87	101	116	130	145	159	174	188	202	217	231	246	260	274	288	
230	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272	287	302	
240	63	79	95	110	126	142	158	174	189	205	221	237	252	268	284	299	314	
250	66	82	99	115	131	148	164	181	197	214	230	247	263	279	296	312	328	
260	68	85	103	120	137	154	171	188	205	222	239	256	273	291	308	325	342	
270	71	89	106	124	142	160	177	195	213	231	248	266	284	302				
280	74	92	110	129	147	166	184	202	221	239	258	276	295					
290	76	95	114	133	153	172	191	210	229	248	267	286	305					
300	79	99	118	138	158	177	197	217	237	256	276	296						
320	84	105	126	147	168	189	210	231	252	273	295							
340	89	112	134	156	179	201	224	246	268	291								
360	95	118	142	166	189	213	237	260	284	308								
380	100	125	150	175	200	225	250	275	300									
400	105	131	158	184	210	237	263	289										
425	112	140	168	196	224	251	279	307										
450	118	148	177	207	237	266	296											
475	125	156	187	219														

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730
Weight per litre		1.20													Figures in body of chart = mm of door opening		
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
20																	
30											26	28	30	32	34		
40																	
50					25	28	32	35	38	41	44	47	50	54	57		
60				26	30	34	38	42	45	49	53	57	60	64	68		
70			26	31	35	40	44	49	53	57	62	66	71	75	79		
80		25	30	35	40	45	50	55	60	66	71	76	81	86	91		
90		28	34	40	45	51	57	62	68	74	79	85	91	96	102		
100	25	32	38	44	50	57	63	69	76	82	88	95	101	107	113		
110	28	35	42	49	55	62	69	76	83	90	97	104	111	118	125		
120	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136		
130	33	41	49	57	66	74	82	90	98	106	115	123	131	139	147		
140	35	44	53	62	71	79	88	97	106	115	123	132	141	150	159		
150	38	47	57	66	76	85	95	104	113	123	132	142	151	161	170		
160	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181		
170	43	54	64	75	86	96	107	118	129	139	150	161	171	182	193		
180	45	57	68	79	91	102	113	125	136	147	159	170	181	193	204		
190	48	60	72	84	96	108	120	132	144	156	168	180	192	203	215		
200	50	63	76	88	101	113	126	139	151	164	176	189	202	214	227		
210	53	66	79	93	106	119	132	146	159	172	185	198	212	225	238		
220	55	69	83	97	111	125	139	152	166	180	194	208	222	236	249		
230	58	72	87	101	116	130	145	159	174	188	203	217	232	246	261		
240	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272		
250	63	79	95	110	126	142	158	173	189	205	221	236	252	268	284		
260	66	82	98	115	131	147	164	180	197	213	229	246	262	278	295		
270	68	85	102	119	136	153	170	187	204	221	238	255	272	289	306		
280	71	88	106	123	141	159	176	194	212	229	247	265	282	300			
290	73	91	110	128	146	164	183	201	219	238	256	274	292				
300	76	95	113	132	151	170	189	208	227	246	265	284	302				
320	81	101	121	141	161	181	202	222	242	262	282	302					
340	86	107	129	150	171	193	214	236	257	278	300						
360	91	113	136	159	181	204	227	249	272	295							
380	96	120	144	168	192	215	239	263	287								
400	101	126	151	176	202	227	252	277	302								
425	107	134	161	187	214	241	268	295									
450	113	142	170	198	227	255	284										
475	120	150	180	209	239	269	299										
500	126	158	189	221	252	284											
525	132	165	198	232	265	298											
550	139	173	208	243	277												
575	145	181	217	254	290												
600	151	189	227	265	302												

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730									
Weight per litre		1.30													Figures in body of chart = mm of door opening											
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36											
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-											
20																										
30														26	28	30	31									
40																										
50													26	28	30	33	35	37	40	42						
60													26	28	30	33	35	37	40	42						
70													28	31	35	38	42	45	49	52	56	59	63			
80													28	33	37	41	45	49	53	57	61	65	69	73		
90													28	33	37	42	47	51	56	60	65	70	74	79	84	
100													26	31	37	42	47	52	58	63	68	73	79	84	89	94
110	26	29	35	41	47	52	58	64	70	77	83	90	96	102	109	115	122	129	136	143	150	157	164	171	178	185
120	28	35	42	49	56	63	70	77	84	91	98	106	113	121	129	136	144	152	160	168	176	184	192	200	208	216
130	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136	144	152	160	168	176	184	192	200	208	216	224
140	33	41	49	57	65	73	81	90	98	106	114	122	130	138	147	155	164	172	180	189	197	206	214	223	231	240
150	35	44	52	61	70	79	87	96	105	113	122	131	140	148	157	166	175	184	193	202	211	220	229	238	247	256
160	37	47	56	65	74	84	93	102	112	121	130	140	149	158	167	176	185	194	203	212	221	230	239	248	257	266
170	40	49	59	69	79	89	99	109	119	129	138	148	158	168	178	187	197	206	215	224	233	242	251	260	269	278
180	42	52	63	73	84	94	105	115	126	136	147	157	167	177	187	197	207	216	225	234	243	252	261	270	279	288
190	44	55	66	77	88	99	110	122	133	144	155	166	177	188	199	209	219	228	237	246	255	264	273	282	291	300
200	47	58	70	81	93	105	116	128	140	151	163	174	186	198	209	220	231	242	253	264	275	286	297	308	319	330
210	49	61	73	85	98	110	122	134	147	159	171	183	195	208	220	232	244	256	268	280	292	304	316	328	340	352
220	51	64	77	90	102	115	128	141	154	166	179	192	205	217	230	243	256	269	282	295	308	321	334	347	360	373
230	54	67	80	94	107	120	134	147	161	174	187	201	214	227	241	254	267	280	293	306	319	332	345	358	371	384
240	56	70	84	98	112	126	140	154	167	181	195	209	223	237	251	265	279	293	307	321	335	349	363	377	391	405
250	58	73	87	102	116	131	145	160	174	189	204	218	233	247	262	276	290	304	318	332	346	360	374	388	402	416
260	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272	287	302	317	332	347	362	377	392	407	422	437
270	63	79	94	110	126	141	157	173	188	204	220	236	251	267	283	298	313	328	343	358	373	388	403	418	433	448
280	65	81	98	114	130	147	163	179	195	212	228	244	261	277	293	309	325	341	357	373	389	405	421	437	453	469
290	67	84	101	118	135	152	169	186	202	219	236	253	270	287	304	321	338	355	372	389	406	423	440	457	474	491
300	70	87	105	122	140	157	174	192	209	227	244	262	279	297	315	333	351	369	387	405	423	441	459	477	495	513
320	74	93	112	130	149	167	186	205	223	242	261	279	298													
340	79	99	119	138	158	178	198	217	237	257	277	297														
360	84	105	126	147	167	188	209	230	251	272	293															
380	88	110	133	155	177	199	221	243	265	287	309															
400	93	116	140	163	186	209	233	256	279	302																
425	99	124	148	173	198	222	247	272	297																	
450	105	131	157	183	209	236	262	288																		
475	110	138	166	193	221	249	276	304																		
500	116	145	174	204	233	262	291		</																	

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730	
Weight per litre		1.40		Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20																		
30																26	28	
40									26	28	30	32	35	37	39			
50							27	30	32	35	38	40	43	46	49			
60					26	29	32	36	39	42	45	49	52	55	58			
70				26	30	34	38	42	45	49	53	57	60	64	68			
80			26	30	35	39	43	48	52	56	60	65	69	73	78			
90			29	34	39	44	49	53	58	63	68	73	78	83	87			
100		27	32	38	43	49	54	59	65	70	76	81	86	92	97			
110		30	36	42	48	53	59	65	71	77	83	89	95	101	107			
120	26	32	39	45	52	58	65	71	78	84	91	97	104	110	117			
130	28	35	42	49	56	63	70	77	84	91	98	105	112	119	126			
140	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136			
150	32	40	49	57	65	73	81	89	97	105	113	121	130	138	146			
160	35	43	52	60	69	78	86	95	104	112	121	130	138	147	156			
170	37	46	55	64	73	83	92	101	110	119	129	138	147	156	165			
180	39	49	58	68	78	87	97	107	117	126	136	146	156	165	175			
190	41	51	62	72	82	92	103	113	123	133	144	154	164	174	185			
200	43	54	65	76	86	97	108	119	130	140	151	162	173	184	194			
210	45	57	68	79	91	102	113	125	136	147	159	170	181	193	204			
220	48	59	71	83	95	107	119	131	143	154	166	178	190	202	214			
230	50	62	75	87	99	112	124	137	149	161	174	186	199	211	224			
240	52	65	78	91	104	117	130	143	156	168	181	194	207	220	233			
250	54	67	81	94	108	121	135	148	162	176	189	202	216	229	243			
260	56	70	84	98	112	126	140	154	168	183	197	211	225	239	253			
270	58	73	87	102	117	131	146	160	175	190	204	219	233	248	262			
280	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272			
290	63	78	94	110	125	141	157	172	188	204	219	235	251	266	282			
300	65	81	97	113	130	146	162	178	194	211	227	243	259	275	292			
320	69	86	104	121	138	156	173	190	207	225	242	259	276	294				
340	73	92	110	129	147	165	184	202	220	239	257	275	294					
360	78	97	117	136	156	175	194	214	233	253	272	292						
380	82	103	123	144	164	185	205	226	246	267	287	308						
400	86	108	130	151	173	194	216	238	259	281	302							
425	92	115	138	161	184	207	229	252	275	298								
450	97	121	146	170	194	219	243	267	292									
475	103	128	154	180	205	231	256	282	308									
500	108	135	162	189	216	243	270	297										
525	113	142	170	198	227	255	283											
550	119	148	178	208	238	267	297											
575	124	155	186	217	248	279												
600	130	162	194	227	259	292												

Gear Box		Low		RATE CHART KG. PER HA.													gb006 730	
Weight per litre		1.50		Figures in body of chart = mm of door opening														
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36			
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
20																		
30																26	27	
40																26	28	
50							25	28	30	33	35	38	40	43	45	30	33	
60							27	30	33	36	39	42	45	48	51	36	39	
70							28	32	35	39	42	46	49	53	56	42	46	
80							28	32	36	40	44	48	52	56	60	48	52	
90			27	32	36	41	45	50	54	59	64	68	73	77	54	59		
100		25	30	35	40	45	50	55	60	66	71	76	81	86	60	66		
110		28	33	39	44	50	55	61	67	72	78	83	89	94	67	72		
120		30	36	42	48	54	60	67	73	79	85	91	97	103	73	79		
130	26	33	39	46	52	59	66	72	79	85	92	98	105	111	79	85		
140	28	35	42	49	56	64	71	78	85	92	99	106	113	120	85	92		
150	30	38	45	53	60	68	76	83	91	98	106	113	121	129	91	98		
160	32	40	48	56	65	73	81	89	97	105	113	121	129	137	97	105		
170	34	43	51	60	69	77	86	94	103	111	120	129	137	146	103	111		
180	36	45	54	64	73	82	91	100	109	118	127	136	145	154	109	118		
190	38	48	57	67	77	86	96	105	115	124	134	144	153	163	115	124		
200	40	50	60	71	81	91	101	111	121	131	141	151	161	171	121	131		
210	42	53	64	74	85	95	106	116	127	138	148	159	169	180	127	138		
220	44	55	67	78	89	100	111	122	133	144	155	166	177	188	133	144		
230	46	58	70	81	93	104	116	128	139	151	162	174	185	197	139	151		
240	48	60	73	85	97	109	121	133	145	157	169	181	194	206	145	157		
250	50	63	76	88	101	113	126	139	151	164	176	189	202	214	151	164		
260	52	66	79	92	105	118	131	144	157	170	183	197	210	223	157	170		
270	54	68	82	95	109	122	136	150	163	177	191	204	218	231	163	177		
280	56	71	85	99	113	127	141	155	169	183	198	212	226	240	169	183		
290	58	73	88	102	117	132	146	161	175	190	205	219	234	248	175	190		
300	60	76	91	106	121	136	151	166	181	197	212	227	242	257	181	197		
320	65	81	97	113	129	145	161	177	194	210	226	242	258	274	194	210		
340	69	86	103	120	137	154	171	188	206	223	240	257	274	291	206	223		
360	73	91	109	127	145	163	181	200	218	236	254	272	290	308	218	236		
380	77	96	115	134	153	172	192	211	230	249	268	287	306		230	249		
400	81	101	121	141	161	181	202	222	242	262	282	302			242	262		
425	86	107	129	150	171	193	214	236	257	278	300				257	278		
450	91	113	136	159	181	204	227	249	272	295					272	295		
475	96	120	144	168	192	215	239	263	287						287			

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART KG. PER H													gb006 730		
Weight per litre		0.70													Figures in body of chart = mm of door opening		
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate																	
100			29	34	38	43	48	53	58	62	67	72	77	82	86		
110		26	32	37	42	48	53	58	63	69	74	79	84	90	95		
120		29	35	40	46	52	58	63	69	75	81	86	92	98	104		
130		31	37	44	50	56	62	69	75	81	87	94	100	106	112		
140	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121		
150	29	36	43	50	58	65	72	79	86	94	101	108	115	122	130		
160	31	38	46	54	61	69	77	84	92	100	108	115	123	131	138		
170	33	41	49	57	65	73	82	90	98	106	114	122	131	139	147		
180	35	43	52	60	69	78	86	95	104	112	121	130	138	147	156		
190	36	46	55	64	73	82	91	100	109	119	128	137	146	155	164		
200	38	48	58	67	77	86	96	106	115	125	134	144	154	163	173		
210	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181		
220	42	53	63	74	84	95	106	116	127	137	148	158	169	180	190		
230	44	55	66	77	88	99	110	121	132	144	155	166	177	188	199		
240	46	58	69	81	92	104	115	127	138	150	161	173	184	196	207		
250	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216		
260	50	62	75	87	100	112	125	137	150	162	175	187	200	212	225		
270	52	65	78	91	104	117	130	143	156	168	181	194	207	220	233		
280	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242		
290	56	70	84	97	111	125	139	153	167	181	195	209	223	237	251		
300	58	72	86	101	115	130	144	158	173	187	202	216	230	245	259		
320	61	77	92	108	123	138	154	169	184	200	215	230	246	261	276		
340	65	82	98	114	131	147	163	180	196	212	228	245	261	277	294		
360	69	86	104	121	138	156	173	190	207	225	242	259	276	294			
380	73	91	109	128	146	164	182	201	219	237	255	274	292				
400	77	96	115	134	154	173	192	211	230	250	269	288	307				
425	82	102	122	143	163	184	204	224	245	265	286	306					
450	86	108	130	151	173	194	216	238	259	281	302						
475	91	114	137	160	182	205	228	251	274	296							
500	96	120	144	168	192	216	240	264	288								
525	101	126	151	176	202	227	252	277	302								
550	106	132	158	185	211	238	264	290									
575	110	138	166	193	221	248	276	304									
600	115	144	173	202	230	259	288										
650	125	156	187	218	250	281											
700	134	168	202	235	269	302											
750	144	180	216	252	288												
800	154	192	230	269	307												
850	163	204	245	286													
900	173	216	259	302													
950	182	228	274														
1000	192	240	288														

Gear Box...Med. Gear		RATE CHART KG. PER H													gb006 730		
Weight per litre		0.75													Figures in body of chart = mm of door opening		
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate																	
100			27	31	36	40	45	49	54	58	63	67	72	76	81		
110			30	34	39	44	49	54	59	64	69	74	79	84	89		
120		27	32	38	43	48	54	59	65	70	75	81	86	91	97		
130		29	35	41	47	52	58	64	70	76	82	87	93	99	105		
140	25	31	38	44	50	56	63	69	75	82	88	94	100	107	113		
150	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121		
160	29	36	43	50	57	65	72	79	86	93	100	108	115	122	129		
170	30	38	46	53	61	69	76	84	91	99	107	114	122	129	137		
180	32	40	48	56	65	73	81	89	97	105	113	121	129	137	145		
190	34	43	51	60	68	77	85	94	102	111	119	128	136	145	153		
200	36	45	54	63	72	81	90	99	108	116	125	134	143	152	161		
210	38	47	56	66	75	85	94	103	113	122	132	141	151	160	169		
220	39	49	59	69	79	89	99	108	118	128	138	148	158	168	177		
230	41	52	62	72	82	93	103	113	124	134	144	155	165	175	185		
240	43	54	65	75	86	97	108	118	129	140	151	161	172	183	194		
250	45	56	67	78	90	101	112	123	134	146	157	168	179	190	202		
260	47	58	70	82	93	105	116	128	140	151	163	175	186	198	210		
270	48	60	73	85	97	109	121	133	145	157	169	181	194	206	218		
280	50	63	75	88	100	113	125	138	151	163	176	188	201	213	226		
290	52	65	78	91	104	117	130	143	156	169	182	195	208	221	234		
300	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242		
320	57	72	86	100	115	129	143	158	172	186	201	215	229	244	258		
340	61	76	91	107	122	137	152	168	183	198	213	228	244	259	274		
360	65	81	97	113	129	145	161	177	194	210	226	242	258	274	290		
380	68	85	102	119	136	153	170	187	204	221	238	255	272	289	306		
400	72	90	108	125	143	161	179	197	215	233	251	269	287	305			
425	76	95	114	133	152	171	190	209	228	248	267	286	305				
450	81	101	121	141	161	181	202	222	242	262	282	302					
475	85	106	128	149	170	192	213	234	255	277	298						
500	90	112	134	157	179	202	224	246	269	291							
525	94	118	141	165	188	212	235	259	282	306							
550	99	123	148	172	197	222	246	271	296								
575	103	129	155	180	206	232	258	283	309								
600	108	134	161	188	215	242	269	296									
650	116	146	175	204	233	262	291										
700	125	157	188	220	251	282											
750	134	168	202	235	269	302											

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART KG. PER H													gb006 730	
Weight per litre		0.80													Figures in body of chart = mm of door opening	
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
100			25	29	34	38	42	46	50	55	59	63	67	71	76	
110			28	32	37	42	46	51	55	60	65	69	74	79	83	
120		25	30	35	40	45	50	55	60	66	71	76	81	86	91	
130		27	33	38	44	49	55	60	66	71	76	82	87	93	98	
140		29	35	41	47	53	59	65	71	76	82	88	94	100	106	
150	25	31	38	44	50	57	63	69	76	82	88	94	101	107	113	
160	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121	
170	29	36	43	50	57	64	71	79	86	93	100	107	114	121	129	
180	30	38	45	53	60	68	76	83	91	98	106	113	121	129	136	
190	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144	
200	34	42	50	59	67	76	84	92	101	109	118	126	134	143	151	
210	35	44	53	62	71	79	88	97	106	115	123	132	141	150	159	
220	37	46	55	65	74	83	92	102	111	120	129	139	148	157	166	
230	39	48	58	68	77	87	97	106	116	126	135	145	155	164	174	
240	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181	
250	42	52	63	74	84	94	105	115	126	136	147	157	168	179	189	
260	44	55	66	76	87	98	109	120	131	142	153	164	175	186	197	
270	45	57	68	79	91	102	113	125	136	147	159	170	181	193	204	
280	47	59	71	82	94	106	118	129	141	153	165	176	188	200	212	
290	49	61	73	85	97	110	122	134	146	158	171	183	195	207	219	
300	50	63	76	88	101	113	126	139	151	164	176	189	202	214	227	
320	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242	
340	57	71	86	100	114	129	143	157	171	186	200	214	228	243	257	
360	60	76	91	106	121	136	151	166	181	197	212	227	242	257	272	
380	64	80	96	112	128	144	160	176	192	207	223	239	255	271	287	
400	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302	
425	71	89	107	125	143	161	178	196	214	232	250	268	286	303		
450	76	94	113	132	151	170	189	208	227	246	265	283	302			
475	80	100	120	140	160	180	199	219	239	259	279	299				
500	84	105	126	147	168	189	210	231	252	273	294					
525	88	110	132	154	176	198	220	243	265	287	309					
550	92	115	139	162	185	208	231	254	277	300						
575	97	121	145	169	193	217	241	266	290							
600	101	126	151	176	202	227	252	277	302							
650	109	136	164	191	218	246	273	300								
700	118	147	176	206	235	265	294									
750	126	157	189	221	252	283										
800	134	168	202	235	269	302										
850	143	178	214	250	286											
900	151	189	227	265	302											
950	160	199	239	279												
1000	168	210	252	294												

Gear Box...Med. Gear		RATE CHART KG. PER H													gb006 730	
Weight per litre		0.85													Figures in body of chart = mm of door opening	
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
100				28	32	36	40	43	47	51	55	59	63	67	71	
110			26	30	35	39	43	48	52	57	61	65	70	74	78	
120		25	28	33	38	43	47	52	57	62	66	71	76	81	85	
130		26	31	36	41	46	51	57	62	67	72	77	82	87	92	
140		28	33	39	44	50	55	61	66	72	77	83	89	94	100	
150		30	36	42	47	53	59	65	71	77	83	89	95	101	107	
160	25	32	38	44	51	57	63	70	76	82	89	95	101	108	114	
170	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121	
180	28	36	43	50	57	64	71	78	85	92	100	107	114	121	128	
190	30	38	45	53	60	68	75	83	90	98	105	113	120	128	135	
200	32	40	47	55	63	71	79	87	95	103	111	119	126	134	142	
210	33	42	50	58	66	75	83	91	100	108	116	125	133	141	149	
220	35	43	52	61	70	78	87	96	104	113	122	130	139	148	157	
230	36	45	55	64	73	82	91	100	109	118	127	136	145	155	164	
240	38	47	57	66	76	85	95	104	114	123	133	142	152	161	171	
250	40	49	59	69	79	89	99	109	119	128	138	148	158	168	178	
260	41	51	62	72	82	92	103	113	123	134	144	154	164	175	185	
270	43	53	64	75	85	96	107	117	128	139	149	160	171	181	192	
280	44	55	66	77	89	100	111	122	133	144	155	166	177	188	199	
290	46	57	69	80	92	103	115	126	138	149	160	172	183	195	206	
300	47	59	71	83	95	107	119	130	142	154	166	178	190	202	213	
320	51	63	76	89	101	114	126	139	152	164	177	190	202	215	228	
340	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242	
360	57	71	85	100	114	128	142	157	171	185	199	213	228	242	256	
380	60	75	90	105	120	135	150	165	180	195	210	225	240	255	270	
400	63	79	95	111	126	142	158	174	190	206	221	237	253	269	285	
425	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302	
450	71	89	107	125	142	160	178	196	213	231	249	267	285	302		
475	75	94	113	131	150	169	188	207	225	244	263	282	300			
500	79	99	119	138	158	178	198	217	237	257	277	296				
525	83	104	125	145	166	187	208	228	249	270	291					
550	87	109	130	152	174	196	217	239	261	283	304					
575	91	114	136	159	182	205	227	250	273	295						
600	95	119	142	166	190	213	237	261	285	308						
650	103	128	154	180	206	231	257	283	308							
700	111	138	166	194	221	249	277	304								
750	119	148	178	208	237	267	296									
800	126	158	190	221	253	285										
850	134	168	202	235	269	302										
900	142	178	213	249	285											
950	150	188	225	263	300											
1000	158	198	237	277												

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART KG. PER H														gb006 730	
Weight per litre		0.90														Figures in body of chart = mm of door opening	
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	Rate	
100				26	30	34	37	41	45	49	52	56	60	63	67		
110				29	33	37	41	45	49	53	57	62	66	70	74		
120			27	31	36	40	45	49	54	58	63	67	72	76	81		
130			29	34	39	44	49	53	58	63	68	73	78	83	87		
140		26	31	37	42	47	52	57	63	68	73	78	84	89	94		
150		28	34	39	45	50	56	62	67	73	78	84	90	95	101		
160		30	36	42	48	54	60	66	72	78	84	90	96	102	108		
170	25	32	38	44	51	57	63	70	76	83	89	95	102	108	114		
180	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121		
190	28	35	43	50	57	64	71	78	85	92	99	106	113	121	128		
200	30	37	45	52	60	67	75	82	90	97	105	112	119	127	134		
210	31	39	47	55	63	71	78	86	94	102	110	118	125	133	141		
220	33	41	49	57	66	74	82	90	99	107	115	123	131	140	148		
230	34	43	52	60	69	77	86	94	103	112	120	129	137	146	155		
240	36	45	54	63	72	81	90	99	108	116	125	134	143	152	161		
250	37	47	56	65	75	84	93	103	112	121	131	140	149	159	168		
260	39	49	58	68	78	87	97	107	116	126	136	146	155	165	175		
270	40	50	60	71	81	91	101	111	121	131	141	151	161	171	181		
280	42	52	63	73	84	94	105	115	125	136	146	157	167	178	188		
290	43	54	65	76	87	97	108	119	130	141	152	162	173	184	195		
300	45	56	67	78	90	101	112	123	134	146	157	168	179	190	202		
320	48	60	72	84	96	108	119	131	143	155	167	179	191	203	215		
340	51	63	76	89	102	114	127	140	152	165	178	190	203	216	228		
360	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242		
380	57	71	85	99	113	128	142	156	170	184	199	213	227	241	255		
400	60	75	90	105	119	134	149	164	179	194	209	224	239	254	269		
425	63	79	95	111	127	143	159	175	190	206	222	238	254	270	286		
450	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302		
475	71	89	106	124	142	160	177	195	213	231	248	266	284	301			
500	75	93	112	131	149	168	187	205	224	243	261	280	299				
525	78	98	118	137	157	176	196	216	235	255	274	294					
550	82	103	123	144	164	185	205	226	246	267	287	308					
575	86	107	129	150	172	193	215	236	258	279	301						
600	90	112	134	157	179	202	224	246	269	291							
650	97	121	146	170	194	218	243	267	291								
700	105	131	157	183	209	235	261	287									
750	112	140	168	196	224	252	280	308									
800	119	149	179	209	239	269	299										
850	127	159	190	222	254	286											
900	134	168	202	235	269	302											
950	142	177	213	248	284												
1000	149	187	224	261	299												

Gear Box...Med. Gear		RATE CHART KG. PER H														gb006 730				
Weight per litre		0.95														Figures in body of chart = mm of door opening				
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	Rate				
100										28	32	35	39	42	46	50	53	57	60	64
110									27	31	35	39	43	47	51	54	58	62	66	70
120			25	30	34	38	42	47	51	55	59	64	68	72	76					
130			28	32	37	41	46	51	55	60	64	69	74	78	83					
140			30	35	40	45	50	54	59	64	69	74	79	84	89					
150		27	32	37	42	48	53	58	64	69	74	80	85	90	95					
160		28	34	40	45	51	57	62	68	74	79	85	91	96	102					
170		30	36	42	48	54	60	66	72	78	84	90	96	102	108					
180	25	32	38	45	51	57	64	70	76	83	89	95	102	108	115					
190	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121					
200	28	35	42	50	57	64	71	78	85	92	99	106	113	120	127					
210	30	37	45	52	59	67	74	82	89	97	104	111	119	126	134					
220	31	39	47	54	62	70	78	86	93	101	109	117	124	132	140					
230	33	41	49	57	65	73	81	89	98	106	114	122	130	138	146					
240	34	42	51	59	68	76	85	93	102	110	119	127	136	144	153					
250	35	44	53	62	71	80	88	97	106	115	124	133	141	150	159					
260	37	46	55	64	74	83	92	101	110	120	129	138	147	156	166					
270	38	48	57	67	76	86	95	105	115	124	134	143	153	162	172					
280	40	50	59	69	79	89	99	109	119	129	139	149	158	168	178					
290	41	51	62	72	82	92	103	113	123	133	144	154	164	174	185					
300	42	53	64	74	85	95	106	117	127	138	149	159	170	180	191					
320	45	57	68	79	91	102	113	124	136	147	158	170	181	192	204					
340	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216					
360	51	64	76	89	102	115	127	140	153	166	178	191	204	216	229					
380	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242					
400	57	71	85	99	113	127	141	156	170	184	198	212	226	241	255					
425	60	75	90	105	120	135	150	165	180	195	210	225	241	256	271					
450	64	80	95	111	127	143	159	175	191	207	223	239	255	271	286					
475	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302					
500	71	88	106	124	141	159	177	195	212	230	248	265	283	301						
525	74	93	111	130	149	167	186	204	223	241	260	279	297							
550	78	97	117	136	156	175	195	214	233	253	272	292								
575	81	102	122	142	163	183	203	224	244	264	285	305								
600	85	106	127	149	170	191	212	233	255	276	297									
650	92	115	138	161	184	207	230	253	276	299										
700	99	124	149	173	198	223	248	272	297											
750	106	133	159	186	212	239	265	292												
800	113	141	170	198	226	255	283													
850	120	150	180	210	241	271	301													
900	127	159	191	223	255	286														
950	134	168	202	235	269	302														
1000	141	177	212	248	283															

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART KG. PER H													gb006 730	
Weight per litre		1.00													Figures in body of chart = mm of door opening	
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
100					27	30	34	37	40	44	47	50	54	57	60	
110				26	30	33	37	41	44	48	52	55	59	63	67	
120				28	32	36	40	44	48	52	56	60	65	69	73	
130				26	31	35	39	44	48	52	57	61	66	70	74	
140				28	33	38	42	47	52	56	61	66	71	75	80	
150		25		30	35	40	45	50	55	60	66	71	76	81	86	
160		27		32	38	43	48	54	59	65	70	75	81	86	91	
170		29		34	40	46	51	57	63	69	74	80	86	91	97	
180		30		36	42	48	54	60	67	73	79	85	91	97	103	
190	26	32		38	45	51	57	64	70	77	83	89	96	102	109	
200	27	34		40	47	54	60	67	74	81	87	94	101	108	114	
210	28	35		42	49	56	64	71	78	85	92	99	106	113	120	
220	30	37		44	52	59	67	74	81	89	96	103	111	118	126	
230	31	39		46	54	62	70	77	85	93	100	108	116	124	131	
240	32	40		48	56	65	73	81	89	97	105	113	121	129	137	
250	34	42		50	59	67	76	84	92	101	109	118	126	134	143	
260	35	44		52	61	70	79	87	96	105	114	122	131	140	149	
270	36	45		54	64	73	82	91	100	109	118	127	136	145	154	
280	38	47		56	66	75	85	94	103	113	122	132	141	151	160	
290	39	49		58	68	78	88	97	107	117	127	136	146	156	166	
300	40	50		60	71	81	91	101	111	121	131	141	151	161	171	
320	43	54		65	75	86	97	108	118	129	140	151	161	172	183	
340	46	57		69	80	91	103	114	126	137	149	160	171	183	194	
360	48	60		73	85	97	109	121	133	145	157	169	181	194	206	
380	51	64		77	89	102	115	128	140	153	166	179	192	204	217	
400	54	67		81	94	108	121	134	148	161	175	188	202	215	228	
425	57	71		86	100	114	129	143	157	171	186	200	214	228	243	
450	60	76		91	106	121	136	151	166	181	197	212	227	242	257	
475	64	80		96	112	128	144	160	176	192	207	223	239	255	271	
500	67	84		101	118	134	151	168	185	202	218	235	252	269	286	
525	71	88		106	123	141	159	176	194	212	229	247	265	282	300	
550	74	92		111	129	148	166	185	203	222	240	259	277	296		
575	77	97		116	135	155	174	193	213	232	251	270	290	309		
600	81	101		121	141	161	181	202	222	242	262	282	302			
650	87	109		131	153	175	197	218	240	262	284	306				
700	94	118		141	165	188	212	235	259	282	306					
750	101	126		151	176	202	227	252	277	302						
800	108	134		161	188	215	242	269	296							
850	114	143		171	200	228	257	286								
900	121	151		181	212	242	272	302								
950	128	160		192	223	255	287									
1000	134	168		202	235	269	302									

Gear Box...Med. Gear		RATE CHART KG. PER H													gb006 730	
Weight per litre		1.05													Figures in body of chart = mm of door opening	
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
100									26	29	32	35	38	42	45	
110									28	32	35	39	42	46	49	
120									27	31	35	38	42	46	50	
130									29	33	37	42	46	50	54	
140									31	36	40	45	49	54	58	
150									29	34	38	43	48	53	58	
160		26							31	36	41	46	51	56	61	
170		27							33	38	44	49	54	60	65	
180		29							35	40	46	52	58	63	69	
190		30							36	43	49	55	61	67	73	
200	26	32							38	45	51	58	64	70	77	
210	27	34							40	47	54	60	67	74	81	
220	28	35							42	49	56	63	70	77	84	
230	29	37							44	52	59	66	74	81	88	
240	31	38							46	54	61	69	77	84	92	
250	32	40							48	56	64	72	80	88	96	
260	33	42							50	58	67	75	83	92	100	
270	35	43							52	60	69	78	86	95	104	
280	36	45							54	63	72	81	90	99	108	
290	37	46							56	65	74	84	93	102	111	
300	38	48							58	67	77	86	96	106	115	
320	41	51							61	72	82	92	102	113	123	
340	44	54							65	76	87	98	109	120	131	
360	46	58							69	81	92	104	115	127	138	
380	49	61							73	85	97	109	122	134	146	
400	51	64							77	90	102	115	128	141	154	
425	54	68							82	95	109	122	136	150	163	
450	58	72							86	101	115	130	144	158	173	
475	61	76							91	106	122	137	152	167	182	
500	64	80							96	112	128	144	160	176	192	
525	67	84							101	118	134	151	168	185	202	
550	70	88							106	123	141	158	176	194	211	
575	74	92							110	129	147	166	184	202	221	
600	77	96							115	134	154	173	192	211	230	
650	83	104							125	146	166	187	208	229	250	
700	90	112							134	157	179	202	224	246	269	
750	96	120							144	168	192	216	240	264	288	
800	102	128							154	179	205	230	256	282	307	
850	109	136							163	190	218	245	272	299		
900	115	144							173	202	230	259	288			
950	122	152							182	213	243	274	304			
1000	128	160							192	224	256	288				

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART KG. PER H													gb006 730	
Weight per litre		1.10													Figures in body of chart = mm of door opening	
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
100						27	31	34	37	40	43	46	49	52	55	
110					27	30	34	37	40	44	47	50	54	57	60	
120				26	29	33	37	40	44	48	51	55	59	62	66	
130				28	32	36	40	44	48	52	56	60	64	68	71	
140			26	30	34	38	43	47	51	56	60	64	68	73	77	
150			27	32	37	41	46	50	55	60	64	69	73	78	82	
160			29	34	39	44	49	54	59	64	68	73	78	83	88	
170	26		31	36	42	47	52	57	62	68	73	78	83	88	93	
180	27		33	38	44	49	55	60	66	71	77	82	88	93	99	
190	29		35	41	46	52	58	64	70	75	81	87	93	99	104	
200	31		37	43	49	55	61	67	73	79	86	92	98	104	110	
210	26	32	38	45	51	58	64	71	77	83	90	96	103	109	115	
220	27	34	40	47	54	60	67	74	81	87	94	101	108	114	121	
230	28	35	42	49	56	63	70	77	84	91	98	105	112	119	126	
240	29	37	44	51	59	66	73	81	88	95	103	110	117	125	132	
250	31	38	46	53	61	69	76	84	92	99	107	115	122	130	137	
260	32	40	48	56	64	71	79	87	95	103	111	119	127	135	143	
270	33	41	49	58	66	74	82	91	99	107	115	124	132	140	148	
280	34	43	51	60	68	77	86	94	103	111	120	128	137	145	154	
290	35	44	53	62	71	80	89	97	106	115	124	133	142	151	159	
300	37	46	55	64	73	82	92	101	110	119	128	137	147	156	165	
320	39	49	59	68	78	88	98	108	117	127	137	147	156	166	176	
340	42	52	62	73	83	93	104	114	125	135	145	156	166	177	187	
360	44	55	66	77	88	99	110	121	132	143	154	165	176	187	198	
380	46	58	70	81	93	104	116	128	139	151	163	174	186	197	209	
400	49	61	73	86	98	110	122	134	147	159	171	183	195	208	220	
425	52	65	78	91	104	117	130	143	156	169	182	195	208	221	234	
450	55	69	82	96	110	124	137	151	165	179	192	206	220	234	247	
475	58	73	87	102	116	131	145	160	174	189	203	218	232	247	261	
500	61	76	92	107	122	137	153	168	183	199	214	229	244	260	275	
525	64	80	96	112	128	144	160	176	192	208	225	241	257	273	289	
550	67	84	101	118	134	151	168	185	202	218	235	252	269	286	302	
575	70	88	105	123	141	158	176	193	211	228	246	263	281	299		
600	73	92	110	128	147	165	183	202	220	238	257	275	293			
650	79	99	119	139	159	179	199	218	238	258	278	298				
700	86	107	128	150	171	192	214	235	257	278	299					
750	92	115	137	160	183	206	229	252	275	298						
800	98	122	147	171	195	220	244	269	293							
850	104	130	156	182	208	234	260	286								
900	110	137	165	192	220	247	275	302								
950	116	145	174	203	232	261	290									
1000	122	153	183	214	244	275	305									

Gear Box...Med. Gear		RATE CHART KG. PER H													gb006 730	
Weight per litre		1.15													Figures in body of chart = mm of door opening	
Width	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate																
100										26	29	32	35	38	41	
110										26	29	32	35	39	42	
120														42	46	
130										27	30	34	38	42	46	
140										29	33	37	41	45	49	
150										31	35	39	44	48	53	
160										26	31	35	39	44	48	
170										28	33	37	42	47	51	
180										30	35	40	45	50	55	
190										26	32	37	42	47	53	
200										28	33	39	44	50	56	
210										29	35	41	47	53	58	
220										31	37	43	49	55	61	
230										26	32	39	45	51	58	
240										27	34	40	47	54	60	
250										28	35	42	49	56	63	
260										29	37	44	51	58	66	
270										30	38	46	53	61	68	
280										32	39	47	55	63	71	
290										33	41	49	57	65	73	
300										34	42	51	59	68	76	
320										35	44	53	61	70	79	
340										37	47	56	65	75	84	
360										40	50	60	70	80	90	
380										42	53	63	74	84	94	
400										44	56	67	78	89	99	
425										47	58	70	82	93	105	
450										50	62	75	87	99	111	
475										53	66	79	92	105	118	
500										56	69	83	97	111	125	
525										58	73	88	102	117	131	
550										61	77	92	107	123	138	
575										64	80	96	112	129	145	
600										67	84	101	118	134	151	
650										76	95	114	133	152	171	
700										82	102	123	143	164	184	
750										88	110	131	153	175	197	
800										93	117	140	164	187	210	
850										99	124	149	174	199	224	
900										105	131	158	184	210	237	
950										111	139	167	194	222	250	
1000										117	146	175	205	234	263	

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													gb006 730																						
Weight per litre		0.70													Figures in body of chart = mm of door opening																						
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36						
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-							
600	36	45	54	64	73	82	91	100	109	118	127	136	145	154	163	600	34	42	51	59	68	76	85	93	102	110	119	127	136	144	152						
625	38	47	57	66	76	85	95	104	113	123	132	142	151	161	170	625	35	44	53	62	71	79	88	97	106	115	124	132	141	150	159						
650	39	49	59	69	79	88	98	108	118	128	138	147	157	167	177	650	37	46	55	64	73	83	92	101	110	119	128	138	147	156	165						
675	41	51	61	71	82	92	102	112	123	133	143	153	163	174	184	675	38	48	57	67	76	86	95	105	114	124	133	143	152	162	172						
700	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191	700	40	49	59	69	79	89	99	109	119	128	138	148	158	168	178						
750	45	57	68	79	91	102	113	125	136	147	159	170	182	193	204	750	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191						
800	48	61	73	85	97	109	121	133	145	157	169	182	194	206	218	800	45	56	68	79	90	102	113	124	136	147	158	169	181	192	203						
850	51	64	77	90	103	116	129	141	154	167	180	193	206	219	231	850	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216						
900	54	68	82	95	109	123	136	150	163	177	191	204	218	231	245	900	51	64	76	89	102	114	127	140	152	165	178	191	203	216	229						
950	57	72	86	101	115	129	144	158	172	187	201	216	230	244	259	950	54	67	80	94	107	121	134	148	161	174	188	201	215	228	241						
1000	61	76	91	106	121	136	151	166	182	197	212	227	242	257	272	1000	56	71	85	99	113	127	141	155	169	184	198	212	226	240	254						
1050	64	79	95	111	127	143	159	175	191	206	222	238	254	270	286	1050	59	74	89	104	119	133	148	163	178	193	208	222	237	252	267						
1100	67	83	100	116	133	150	166	183	200	216	233	250	266	283	299	1100	62	78	93	109	124	140	155	171	186	202	217	233	248	264	280						
1150	70	87	104	122	139	157	174	191	209	226	244	261	278	296		1150	65	81	97	114	130	146	162	179	195	211	227	244	260	276	292						
1200	73	91	109	127	145	163	182	200	218	236	254	272	290	309		1200	68	85	102	119	136	152	169	186	203	220	237	254	271	288	305						
1250	76	95	113	132	151	170	189	208	227	246	265	284	303		1250	71	88	106	124	141	159	176	194	212	229	247	265	282	300								
1300	79	98	118	138	157	177	197	216	236	256	275	295			1300	73	92	110	128	147	165	184	202	220	239	257	275	294									
1350	82	102	123	143	163	184	204	225	245	265	286	306			1350	76	95	114	133	152	172	191	210	229	248	267	286	305									
1400	85	106	127	148	169	191	212	233	254	275	296				1400	79	99	119	138	158	178	198	217	237	257	277	296										
1450	88	110	132	154	175	197	219	241	263	285	307				1450	82	102	123	143	164	184	205	225	246	266	287	307										
1500	91	113	136	159	182	204	227	250	272	295					1500	85	106	127	148	169	191	212	233	254	275	296											
1550	94	117	141	164	188	211	234	258	281	305					1550	88	109	131	153	175	197	219	241	263	284	306											
1600	97	121	145	169	194	218	242	266	290						1600	90	113	136	158	181	203	226	248	271	294												
1650	100	125	150	175	200	225	250	275	299						1650	93	116	140	163	186	210	233	256	280	303												
1700	103	129	154	180	206	231	257	283	309						1700	96	120	144	168	192	216	240	264	288													
1800	109	136	163	191	218	245	272	299							1800	102	127	152	178	203	229	254	280	305													
1900	115	144	172	201	230	259	287								1900	107	134	161	188	215	241	268	295														
2000	121	151	182	212	242	272	303								2000	113	141	169	198	226	254	282															
2500	151	189	227	265	303										2500	141	176	212	247	282																	
3000	182	227	272												3000	169	212	254	296																		
3500	212	265													3500	198	247	296																			
4000	242	303													4000	226	282																				
5000	303														5000	282																					
6000															6000																						
7000															7000																						
8000															8000																						
9000															9000																						
10000															10000																						

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													gb006 730
Weight per litre		0.80													Figures in body of chart = mm of door opening
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600	32	40	48	56	64	71	79	87	95	103	111	119	127	135	143
625	33	41	50	58	66	74	83	91	99	108	116	124	132	141	149
650	34	43	52	60	69	77	86	95	103	112	120	129	138	146	155
675	36	45	54	63	71	80	89	98	107	116	125	134	143	152	161
700	37	46	56	65	74	83	93	102	111	120	130	139	148	157	167
750	40	50	60	69	79	89	99	109	119	129	139	149	159	169	179
800	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191
850	45	56	67	79	90	101	112	124	135	146	157	169	180	191	202
900	48	60	71	83	95	107	119	131	143	155	167	179	191	202	214
950	50	63	75	88	101	113	126	138	151	163	176	189	201	214	226
1000	53	66	79	93	106	119	132	146	159	172	185	199	212	225	238
1050	56	69	83	97	111	125	139	153	167	181	195	208	222	236	250
1100	58	73	87	102	116	131	146	160	175	189	204	218	233	247	262
1150	61	76	91	107	122	137	152	167	183	198	213	228	244	259	274
1200	64	79	95	111	127	143	159	175	191	206	222	238	254	270	286
1250	66	83	99	116	132	149	165	182	199	215	232	248	265	281	298
1300	69	86	103	120	138	155	172	189	206	224	241	258	275	292	310
1350	71	89	107	125	143	161	179	197	214	232	250	268	286	304	
1400	74	93	111	130	148	167	185	204	222	241	259	278	296		
1450	77	96	115	134	154	173	192	211	230	249	269	288	307		
1500	79	99	119	139	159	179	199	218	238	258	278	298			
1550	82	103	123	144	164	185	205	226	246	267	287	308			
1600	85	106	127	148	169	191	212	233	254	275	296				
1650	87	109	131	153	175	197	218	240	262	284	306				
1700	90	112	135	157	180	202	225	247	270	292					
1800	95	119	143	167	191	214	238	262	286	310					
1900	101	126	151	176	201	226	251	277	302						
2000	106	132	159	185	212	238	265	291							
2500	132	165	199	232	265	298									
3000	159	199	238	278											
3500	185	232	278												
4000	212	265													
5000	265														
6000															
7000															
8000															
9000															
10000															

Gear Box...High. Gear		RATE CHART KG. PER HA.													gb006 730
Weight per litre		0.85													Figures in body of chart = mm of door opening
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600	30	37	45	52	60	67	75	82	90	97	105	112	120	127	135
625	31	39	47	54	62	70	78	86	93	101	109	117	125	132	140
650	32	40	49	57	65	73	81	89	97	105	113	121	130	138	146
675	34	42	50	59	67	76	84	92	101	109	118	126	135	143	151
700	35	44	52	61	70	78	87	96	105	113	122	131	140	148	157
750	37	47	56	65	75	84	93	103	112	121	131	140	149	159	168
800	40	50	60	70	80	90	100	110	120	130	140	149	159	169	179
850	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191
900	45	56	67	78	90	101	112	123	135	146	157	168	179	191	202
950	47	59	71	83	95	106	118	130	142	154	166	177	189	201	213
1000	50	62	75	87	100	112	125	137	149	162	174	187	199	212	224
1050	52	65	78	92	105	118	131	144	157	170	183	196	209	222	235
1100	55	69	82	96	110	123	137	151	164	178	192	206	219	233	247
1150	57	72	86	100	115	129	143	158	172	186	201	215	229	244	258
1200	60	75	90	105	120	135	149	164	179	194	209	224	239	254	269
1250	62	78	93	109	125	140	156	171	187	202	218	234	249	265	280
1300	65	81	97	113	130	146	162	178	194	211	227	243	259	275	291
1350	67	84	101	118	135	151	168	185	202	219	235	252	269	286	303
1400	70	87	105	122	140	157	174	192	209	227	244	262	279	296	
1450	72	90	108	126	144	163	181	199	217	235	253	271	289	307	
1500	75	93	112	131	149	168	187	206	224	243	262	280	299		
1550	77	97	116	135	154	174	193	212	232	251	270	290	309		
1600	80	100	120	140	159	179	199	219	239	259	279	299			
1650	82	103	123	144	164	185	206	226	247	267	288	308			
1700	85	106	127	148	169	191	212	233	254	275	296				
1800	90	112	135	157	179	202	224	247	269	291					
1900	95	118	142	166	189	213	237	260	284	308					
2000	100	125	149	174	199	224	249	274	299						
2500	125	156	187	218	249	280									
3000	149	187	224	262	299										
3500	174	218	262	305											
4000	199	249	299												
5000	249														
6000	299														
7000															
8000															
9000															
10000															

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													gb006 730																
Weight per litre		0.90													Figures in body of chart = mm of door opening																
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600	28	35	42	49	56	64	71	78	85	92	99	106	113	120	127	600	27	33	40	47	53	60	67	74	80	87	94	100	107	114	120
625	29	37	44	51	59	66	74	81	88	96	103	110	118	125	132	625	28	35	42	49	56	63	70	77	84	91	98	104	111	118	125
650	31	38	46	54	61	69	76	84	92	99	107	115	122	130	138	650	29	36	43	51	58	65	72	80	87	94	101	109	116	123	130
675	32	40	48	56	64	71	79	87	95	103	111	119	127	135	143	675	30	38	45	53	60	68	75	83	90	98	105	113	120	128	135
700	33	41	49	58	66	74	82	91	99	107	115	124	132	140	148	700	31	39	47	55	62	70	78	86	94	101	109	117	125	133	140
750	35	44	53	62	71	79	88	97	106	115	124	132	141	150	159	750	33	42	50	59	67	75	84	92	100	109	117	125	134	142	150
800	38	47	56	66	75	85	94	104	113	122	132	141	151	160	169	800	36	45	53	62	71	80	89	98	107	116	125	134	143	152	160
850	40	50	60	70	80	90	100	110	120	130	140	150	160	170	180	850	38	47	57	66	76	85	95	104	114	123	133	142	152	161	171
900	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191	900	40	50	60	70	80	90	100	110	120	130	140	150	160	171	181
950	45	56	67	78	89	101	112	123	134	145	156	168	179	190	201	950	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191
1000	47	59	71	82	94	106	118	129	141	153	165	176	188	200	212	1000	45	56	67	78	89	100	111	123	134	145	156	167	178	189	201
1050	49	62	74	86	99	111	124	136	148	161	173	185	198	210	222	1050	47	59	70	82	94	105	117	129	140	152	164	176	187	199	211
1100	52	65	78	91	104	116	129	142	155	168	181	194	207	220	233	1100	49	61	74	86	98	110	123	135	147	159	172	184	196	208	221
1150	54	68	81	95	108	122	135	149	162	176	189	203	216	230	244	1150	51	64	77	90	103	115	128	141	154	167	179	192	205	218	231
1200	56	71	85	99	113	127	141	155	169	184	198	212	226	240	254	1200	53	67	80	94	107	120	134	147	160	174	187	201	214	227	241
1250	59	74	88	103	118	132	147	162	176	191	206	221	235	250	265	1250	56	70	84	98	111	125	139	153	167	181	195	209	223	237	251
1300	61	76	92	107	122	138	153	168	184	199	214	229	245	260	275	1300	58	72	87	101	116	130	145	159	174	188	203	217	232	246	261
1350	64	79	95	111	127	143	159	175	191	206	222	238	254	270	286	1350	60	75	90	105	120	135	150	165	181	196	211	226	241	256	271
1400	66	82	99	115	132	148	165	181	198	214	231	247	264	280	296	1400	62	78	94	109	125	140	156	172	187	203	218	234	250	265	281
1450	68	85	102	119	136	154	171	188	205	222	239	256	273	290	307	1450	65	81	97	113	129	145	162	178	194	210	226	242	259	275	291
1500	71	88	106	124	141	159	176	194	212	229	247	265	282	300		1500	67	84	100	117	134	150	167	184	201	217	234	251	267	284	301
1550	73	91	109	128	146	164	182	201	219	237	255	274	292	310		1550	69	86	104	121	138	155	173	190	207	225	242	259	276	294	
1600	75	94	113	132	151	169	188	207	226	245	264	282	301		1600	71	89	107	125	143	160	178	196	214	232	250	267	285	303		
1650	78	97	116	136	155	175	194	214	233	252	272	291			1650	74	92	110	129	147	165	184	202	221	239	257	276	294			
1700	80	100	120	140	160	180	200	220	240	260	280	300			1700	76	95	114	133	152	171	189	208	227	246	265	284	303			
1800	85	106	127	148	169	191	212	233	254	275	296				1800	80	100	120	140	160	181	201	221	241	261	281	301				
1900	89	112	134	156	179	201	224	246	268	291					1900	85	106	127	148	169	191	212	233	254	275	296					
2000	94	118	141	165	188	212	235	259	282	306					2000	89	111	134	156	178	201	223	245	267	290						
2500	118	147	176	206	235	265	294								2500	111	139	167	195	223	251	279	306								
3000	141	176	212	247	282										3000	134	167	201	234	267	301										
3500	165	206	247	288											3500	156	195	234	273												
4000	188	235	282												4000	178	223	267													
5000	235	294													5000	223	279														
6000	282														6000	267															
7000															7000																
8000															8000																
9000															9000																
10000															10000																

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													gb006 730																		
Weight per litre		1.00													Figures in body of chart = mm of door opening																		
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36		
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
600	25	32	38	44	51	57	64	70	76	83	89	95	102	108	114	600		30	36	42	48	54	61	67	73	79	85	91	97	103	109		
625	26	33	40	46	53	60	66	73	79	86	93	99	106	112	119	625	25	32	38	44	50	57	63	69	76	82	88	95	101	107	113		
650	28	34	41	48	55	62	69	76	83	89	96	103	110	117	124	650	26	33	39	46	52	59	66	72	79	85	92	98	105	111	118		
675	29	36	43	50	57	64	71	79	86	93	100	107	114	121	129	675	27	34	41	48	54	61	68	75	82	88	95	102	109	116	123		
700	30	37	44	52	59	67	74	82	89	96	104	111	119	126	133	700	28	35	42	49	56	64	71	78	85	92	99	106	113	120	127		
750	32	40	48	56	64	71	79	87	95	103	111	119	127	135	143	750	30	38	45	53	61	68	76	83	91	98	106	113	121	129	136		
800	34	42	51	59	68	76	85	93	102	110	119	127	136	144	152	800	32	40	48	56	65	73	81	89	97	105	113	121	129	137	145		
850	36	45	54	63	72	81	90	99	108	117	126	135	144	153	162	850	34	43	51	60	69	77	86	94	103	111	120	129	137	146	154		
900	38	48	57	67	76	86	95	105	114	124	133	143	152	162	172	900	36	45	54	64	73	82	91	100	109	118	127	136	145	154	163		
950	40	50	60	70	80	91	101	111	121	131	141	151	161	171	181	950	38	48	57	67	77	86	96	105	115	125	134	144	153	163	172		
1000	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191	1000	40	50	61	71	81	91	101	111	121	131	141	151	161	171	182		
1050	44	56	67	78	89	100	111	122	133	145	156	167	178	189	200	1050	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191		
1100	47	58	70	82	93	105	116	128	140	151	163	175	186	198	210	1100	44	55	67	78	89	100	111	122	133	144	155	166	177	189	200		
1150	49	61	73	85	97	110	122	134	146	158	170	183	195	207	219	1150	46	58	70	81	93	104	116	128	139	151	162	174	186	197	209		
1200	51	64	76	89	102	114	127	140	152	165	178	191	203	216	229	1200	48	61	73	85	97	109	121	133	145	157	169	182	194	206	218		
1250	53	66	79	93	106	119	132	146	159	172	185	199	212	225	238	1250	50	63	76	88	101	113	126	139	151	164	176	189	202	214	227		
1300	55	69	83	96	110	124	138	151	165	179	193	206	220	234	248	1300	52	66	79	92	105	118	131	144	157	170	184	197	210	223	236		
1350	57	71	86	100	114	129	143	157	172	186	200	214	229	243	257	1350	54	68	82	95	109	123	136	150	163	177	191	204	218	231	245		
1400	59	74	89	104	119	133	148	163	178	193	208	222	237	252	267	1400	56	71	85	99	113	127	141	155	169	184	198	212	226	240	254		
1450	61	77	92	107	123	138	154	169	184	200	215	230	246	261	276	1450	58	73	88	102	117	132	146	161	175	190	205	219	234	249	263		
1500	64	79	95	111	127	143	159	175	191	206	222	238	254	270	286	1500	61	76	91	106	121	136	151	166	182	197	212	227	242	257	272		
1550	66	82	98	115	131	148	164	181	197	213	230	246	263	279	295	1550	63	78	94	109	125	141	156	172	188	203	219	234	250	266	281		
1600	68	85	102	119	136	152	169	186	203	220	237	254	271	288	305	1600	65	81	97	113	129	145	161	177	194	210	226	242	258	274	290		
1650	70	87	105	122	140	157	175	192	210	227	245	262	280	297		1650	67	83	100	116	133	150	166	183	200	216	233	250	266	283	299		
1700	72	90	108	126	144	162	180	198	216	234	252	270	288	306		1700	69	86	103	120	137	154	171	189	206	223	240	257	274	291	309		
1800	76	95	114	133	152	172	191	210	229	248	267	286	305			1800	73	91	109	127	145	163	182	200	218	236	254	272	290	309			
1900	80	101	121	141	161	181	201	221	241	262	282	302				1900	77	96	115	134	153	172	192	211	230	249	268	287	307				
2000	85	106	127	148	169	191	212	233	254	275	296					2000	81	101	121	141	161	182	202	222	242	262	282	303					
2500	106	132	159	185	212	238	265	291								2500	101	126	151	176	202	227	252	277	303								
3000	127	159	191	222	254	286										3000	121	151	182	212	242	272	303										
3500	148	185	222	259	296											3500	141	176	212	247	282												
4000	169	212	254	296												4000	161	202	242	282													
5000	212	265														5000	202	252	303														
6000	254															6000	242	303															
7000	296															7000	282																
8000																8000																	
9000																9000																	
10000																10000																	

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													gb006 730																
Weight per litre		1.20													Figures in body of chart = mm of door opening																
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600		26	32	37	42	48	53	58	64	69	74	79	85	90	95	600			29	34	39	44	49	54	59	64	68	73	78	83	88
625		28	33	39	44	50	55	61	66	72	77	83	88	94	99	625	25	31	36	41	46	51	56	61	66	71	76	81	87	92	
650		29	34	40	46	52	57	63	69	75	80	86	92	97	103	650	26	32	37	42	48	53	58	64	69	74	79	85	90	95	
675		30	36	42	48	54	60	66	71	77	83	89	95	101	107	675	27	33	38	44	49	55	60	66	71	77	82	88	93	99	
700		31	37	43	49	56	62	68	74	80	86	93	99	105	111	700	29	34	40	46	51	57	63	68	74	80	86	91	97	103	
750	26	33	40	46	53	60	66	73	79	86	93	99	106	112	119	750	31	37	43	49	55	61	67	73	79	86	92	98	104	110	
800	28	35	42	49	56	64	71	78	85	92	99	106	113	120	127	800	26	33	39	46	52	59	65	72	78	85	91	98	104	111	117
850	30	37	45	52	60	67	75	82	90	97	105	112	120	127	135	850	28	35	42	48	55	62	69	76	83	90	97	104	111	118	125
900	32	40	48	56	64	71	79	87	95	103	111	119	127	135	143	900	29	37	44	51	59	66	73	81	88	95	103	110	117	125	132
950	34	42	50	59	67	75	84	92	101	109	117	126	134	142	151	950	31	39	46	54	62	70	77	85	93	101	108	116	124	132	139
1000	35	44	53	62	71	79	88	97	106	115	124	132	141	150	159	1000	33	41	49	57	65	73	81	90	98	106	114	122	130	138	147
1050	37	46	56	65	74	83	93	102	111	120	130	139	148	157	167	1050	34	43	51	60	68	77	86	94	103	111	120	128	137	145	154
1100	39	49	58	68	78	87	97	107	116	126	136	146	155	165	175	1100	36	45	54	63	72	81	90	99	108	116	125	134	143	152	161
1150	41	51	61	71	81	91	101	112	122	132	142	152	162	172	183	1150	37	47	56	66	75	84	94	103	112	122	131	140	150	159	169
1200	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191	1200	39	49	59	68	78	88	98	108	117	127	137	147	156	166	176
1250	44	55	66	77	88	99	110	121	132	143	154	165	176	187	199	1250	41	51	61	71	81	92	102	112	122	132	143	153	163	173	183
1300	46	57	69	80	92	103	115	126	138	149	161	172	184	195	206	1300	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191
1350	48	60	71	83	95	107	119	131	143	155	167	179	191	202	214	1350	44	55	66	77	88	99	110	121	132	143	154	165	176	187	198
1400	49	62	74	86	99	111	124	136	148	161	173	185	198	210	222	1400	46	57	68	80	91	103	114	125	137	148	160	171	182	194	205
1450	51	64	77	90	102	115	128	141	154	166	179	192	205	217	230	1450	47	59	71	83	94	106	118	130	142	154	165	177	189	201	213
1500	53	66	79	93	106	119	132	146	159	172	185	199	212	225	238	1500	49	61	73	86	98	110	122	134	147	159	171	183	195	208	220
1550	55	68	82	96	109	123	137	150	164	178	191	205	219	232	246	1550	50	63	76	88	101	114	126	139	151	164	177	189	202	215	227
1600	56	71	85	99	113	127	141	155	169	184	198	212	226	240	254	1600	52	65	78	91	104	117	130	143	156	169	182	195	208	222	235
1650	58	73	87	102	116	131	146	160	175	189	204	218	233	247	262	1650	54	67	81	94	108	121	134	148	161	175	188	202	215	228	242
1700	60	75	90	105	120	135	150	165	180	195	210	225	240	255	270	1700	55	69	83	97	111	125	138	152	166	180	194	208	222	235	249
1800	64	79	95	111	127	143	159	175	191	206	222	238	254	270	286	1800	59	73	88	103	117	132	147	161	176	191	205	220	235	249	264
1900	67	84	101	117	134	151	168	184	201	218	235	251	268	285	302	1900	62	77	93	108	124	139	155	170	186	201	217	232	248	263	279
2000	71	88	106	124	141	159	176	194	212	229	247	265	282	300		2000	65	81	98	114	130	147	163	179	195	212	228	244	261	277	293
2500	88	110	132	154	176	199	221	243	265	287	309					2500	81	102	122	143	163	183	204	224	244	265	285	305			
3000	106	132	159	185	212	238	265	291								3000	98	122	147	171	195	220	244	269	293						
3500	124	154	185	216	247	278	309									3500	114	143	171	200	228	257	285								
4000	141	176	212	247	282											4000	130	163	195	228	261	293									
5000	176	221	265	309												5000	163	204	244	285											
6000	212	265														6000	195	244	293												
7000	247	309														7000	228	285													
8000	282															8000	261														
9000																9000	293														
10000																10000															

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
 Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART KG. PER HA.													gb006 730																	
Weight per litre		1.40													Figures in body of chart = mm of door opening																	
Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	Width.	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	
Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	Rate	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
600			27	32	36	41	45	50	54	59	64	68	73	77	82	600			25	30	34	38	42	47	51	55	59	64	68	72	76	
625			28	33	38	43	47	52	57	61	66	71	76	80	85	625			26	31	35	40	44	49	53	57	62	66	71	75	79	
650			29	34	39	44	49	54	59	64	69	74	79	84	88	650			28	32	37	41	46	50	55	60	64	69	73	78	83	
675		26	31	36	41	46	51	56	61	66	71	77	82	87	92	675			29	33	38	43	48	52	57	62	67	71	76	81	86	
700		26	32	37	42	48	53	58	64	69	74	79	85	90	95	700			30	35	40	44	49	54	59	64	69	74	79	84	89	
750		28	34	40	45	51	57	62	68	74	79	85	91	96	102	750		26	32	37	42	48	53	58	64	69	74	79	85	90	95	
800		30	36	42	48	54	61	67	73	79	85	91	97	103	109	800		28	34	40	45	51	56	62	68	73	79	85	90	96	102	
850	26	32	39	45	51	58	64	71	77	84	90	96	103	109	116	850		30	36	42	48	54	60	66	72	78	84	90	96	102	108	
900	27	34	41	48	54	61	68	75	82	88	95	102	109	116	123	900	25	32	38	44	51	57	64	70	76	83	89	95	102	108	114	
950	29	36	43	50	57	65	72	79	86	93	101	108	115	122	129	950	27	34	40	47	54	60	67	74	80	87	94	101	107	114	121	
1000	30	38	45	53	61	68	76	83	91	98	106	113	121	129	136	1000	28	35	42	49	56	64	71	78	85	92	99	106	113	120	127	
1050	32	40	48	56	64	71	79	87	95	103	111	119	127	135	143	1050	30	37	44	52	59	67	74	82	89	96	104	111	119	126	133	
1100	33	42	50	58	67	75	83	92	100	108	116	125	133	141	150	1100	31	39	47	54	62	70	78	85	93	101	109	116	124	132	140	
1150	35	43	52	61	70	78	87	96	104	113	122	130	139	148	157	1150	32	41	49	57	65	73	81	89	97	106	114	122	130	138	146	
1200	36	45	54	64	73	82	91	100	109	118	127	136	145	154	163	1200	34	42	51	59	68	76	85	93	102	110	119	127	136	144	152	
1250	38	47	57	66	76	85	95	104	113	123	132	142	151	161	170	1250	35	44	53	62	71	79	88	97	106	115	124	132	141	150	159	
1300	39	49	59	69	79	88	98	108	118	128	138	147	157	167	177	1300	37	46	55	64	73	83	92	101	110	119	128	138	147	156	165	
1350	41	51	61	71	82	92	102	112	123	133	143	153	163	174	184	1350	38	48	57	67	76	86	95	105	114	124	133	143	152	162	172	
1400	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191	1400	40	49	59	69	79	89	99	109	119	128	138	148	158	168	178	
1450	44	55	66	77	88	99	110	121	132	143	154	164	175	186	197	1450	41	51	61	72	82	92	102	113	123	133	143	154	164	174	184	
1500	45	57	68	79	91	102	113	125	136	147	159	170	182	193	204	1500	42	53	64	74	85	95	106	116	127	138	148	159	169	180	191	
1550	47	59	70	82	94	105	117	129	141	152	164	176	188	199	211	1550	44	55	66	77	88	98	109	120	131	142	153	164	175	186	197	
1600	48	61	73	85	97	109	121	133	145	157	169	182	194	206	218	1600	45	56	68	79	90	102	113	124	136	147	158	169	181	192	203	
1650	50	62	75	87	100	112	125	137	150	162	175	187	200	212	225	1650	47	58	70	82	93	105	116	128	140	151	163	175	186	198	210	
1700	51	64	77	90	103	116	129	141	154	167	180	193	206	219	231	1700	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216	
1800	54	68	82	95	109	123	136	150	163	177	191	204	218	231	245	1800	51	64	76	89	102	114	127	140	152	165	178	191	203	216	229	
1900	57	72	86	101	115	129	144	158	172	187	201	216	230	244	259	1900	54	67	80	94	107	121	134	148	161	174	188	201	215	228	241	
2000	61	76	91	106	121	136	151	166	182	197	212	227	242	257	272	2000	56	71	85	99	113	127	141	155	169	184	198	212	226	240	254	
2500	76	95	113	132	151	170	189	208	227	246	265	284	303			2500	71	88	106	124	141	159	176	194	212	229	247	265	282	300		
3000	91	113	136	159	182	204	227	250	272	295						3000	85	106	127	148	169	191	212	233	254	275	296					
3500	106	132	159	185	212	238	265	291								3500	99	124	148	173	198	222	247	272	296							
4000	121	151	182	212	242	272	303									4000	113	141	169	198	226	254	282									
5000	151	189	227	265	303											5000	141	176	212	247	282											
6000	182	227	272													6000	169	212	254	296												
7000	212	265														7000	198	247	296													
8000	242	303														8000	226	282														
9000	272															9000	254															
10000	303															10000	282															

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

For Use with [TRANSPREAD](#) Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.

For Use with **TRANSPREAD** Density Meter, Transpread Gear Box, gb006, Standard Jockey..730.. Accuracy of final settings operators responsibility on use
Other rates and rate calculator can be viewed at <http://www.transpread.com/Trailers/Homepage.htm>, also available in XL format for your own computer.