

For Use with [TRANSPREAD](#) Density Meter ..gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		45													Figures in body of chart = mm of door opening	
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
20											26	30	34	37	45	45
30											39	45	51	56	56	67
40											49	52	60	67	75	90
50			28	33	37	42	47	51	56	61	66	75	84	94	94	112
60	28	34	39	45	51	56	62	67	73	79	90	101	112	112	135	135
70	33	39	46	52	59	66	72	79	85	92	105	118	131	131	157	157
80	37	45	52	60	67	75	82	90	97	105	120	135	150	150	180	180
90	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	202
100	47	56	66	75	84	94	103	112	122	131	150	168	187	187	225	225
110	51	62	72	82	93	103	113	124	134	144	165	185	206	206	247	247
120	56	67	79	90	101	112	124	135	146	157	180	202	225	225	270	270
130	61	73	85	97	110	122	134	146	158	170	195	219	243	243	292	292
140	66	79	92	105	118	131	144	157	170	183	210	236	262	262		
150	70	84	98	112	126	140	154	168	183	197	225	253	281	281		
160	75	90	105	120	135	150	165	180	195	210	240	270	300	300		
170	80	95	111	127	143	159	175	191	207	223	255	286				
180	84	101	118	135	152	168	185	202	219	236	270					
190	89	107	124	142	160	178	196	213	231	249	285					
200	94	112	131	150	168	187	206	225	243	262	300					
210	98	118	138	157	177	197	216	236	256	275						
220	103	124	144	165	185	206	227	247	268	288						
230	108	129	151	172	194	215	237	258	280							
240	112	135	157	180	202	225	247	270	292							
250	117	140	164	187	211	234	257	281								
260	122	146	170	195	219	243	268	292								
270	126	152	177	202	227	253	278									
280	131	157	183	210	236	262	288									
290	136	163	190	217	244	271	299									
300	140	168	197	225	253	281										
320	150	180	210	240	270	300										
340	159	191	223	255	286											
360	168	202	236	270												
380	178	213	249	285												
400	187	225	262	300												
425	199	239	278													
450	211	253	295													
475	222	267														
500	234	281														
525	246	295														
550	257															
575	269															
600	281															

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		50													Figures in body of chart = mm of door opening	
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
20																
30																
40																
50			25	29	34	38	42	46	51	55	59	67	76	84	94	101
60	25	30	35	40	45	51	56	61	66	71	81	91	101	101	101	121
70	29	35	41	47	53	59	65	71	77	83	94	106	118	118	142	142
80	34	40	47	54	61	67	74	81	88	94	108	121	135	135	162	162
90	38	45	53	61	68	76	83	91	99	106	121	136	152	152	182	182
100	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	202
110	46	56	65	74	83	93	102	111	120	130	148	167	185	185	222	222
120	51	61	71	81	91	101	111	121	131	142	162	182	202	202	243	243
130	55	66	77	88	99	110	120	131	142	153	175	197	219	219	263	263
140	59	71	83	94	106	118	130	142	153	165	189	212	236	236	283	283
150	63	76	88	101	114	126	139	152	164	177	202	227	253	253		
160	67	81	94	108	121	135	148	162	175	189	216	243	270	270		
170	72	86	100	115	129	143	158	172	186	200	229	258	286	286		
180	76	91	106	121	136	152	167	182	197	212	243	273				
190	80	96	112	128	144	160	176	192	208	224	256	288				
200	84	101	118	135	152	168	185	202	219	236	270					
210	88	106	124	142	159	177	195	212	230	248	283					
220	93	111	130	148	167	185	204	222	241	259	297					
230	97	116	136	155	174	194	213	233	252	271						
240	101	121	142	162	182	202	222	243	263	283						
250	105	126	147	168	190	211	232	253	274	295						
260	110	131	153	175	197	219	241	263	285							
270	114	136	159	182	205	227	250	273	296							
280	118	142	165	189	212	236	259	283								
290	122	147	171	195	220	244	269	293								
300	126	152	177	202	227	253	278									
320	135	162	189	216	243	270	297									
340	143	172	200	229	258	286										
360	152	182	212	243	273											
380	160	192	224	256	288											
400	168	202	236	270												
425	179	215	251	286												
450	190	227	265													
475	200	240	280													
500	211	253	295													
525	221	265														
550	232	278														
575	242	291														
600	253															

For Use with [TRANSPREAD](#) Density Meter ..gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		55													Figures in body of chart = mm of door opening	
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
20													28	31	37	37
30								25	28	30	32	37	41	46	46	55
40								34	37	40	43	49	55	61	61	74
50								42	46	50	54	61	69	77	77	92
60			28	32	37	41	46	51	55	60	64	74	83	92	92	110
70	27	32	38	43	48	54	59	64	70	75	86	96	107	107	129	129
80	31	37	43	49	55	61	67	74	80	86	98	110	123	123	147	147
90	34	41	48	55	62	69	76	83	90	96	110	124	138	138	165	165
100	38	46	54	61	69	77	84	92	100	107	123	138	153	153	184	184
110	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	202
120	46	55	64	74	83	92	101	110	119	129	147	165	184	184	221	221
130	50	60	70	80	90	100	110	119	129	139	159	179	199	199	239	239
140	54	64	75	86	96	107	118	129	139	150	172	193	214	214	257	257
150	57	69	80	92	103	115	126	138	149	161	184	207	230	230	276	276
160	61	74	86	98	110	123	135	147	159	172	196	221	245	245	294	294
170	65	78	91	104	117	130	143	156	169	182	208	234	260	260		
180	69	83	96	110	124	138	152	165	179	193	221	248	276	276		
190	73	87	102	116	131	146	160	175	189	204	233	262	291	291		
200	77	92	107	123	138	153	168	184	199	214	245	276				
210	80	96	113	129	145	161	177	193	209	225	257	289				
220	84	101	118	135	152	168	185	202	219	236	270					
230	88	106	123	141	159	176	194	211	229	247	282					
240	92	110	129	147	165	184	202	221	239	257	294					
250	96	115	134	153	172	191	211	230	249	268						
260	100	119	139	159	179	199	219	239	259	279						
270	103	124	145	165	186	207	227	248	269	289						
280	107	129	150	172	193	214	236	257	279							
290	111	133	155	178	200	222	244	267	289							
300	115	138	161	184	207	230	253	276	299							
320	123	147	172	196	221	245	270	294								
340	130	156	182	208	234	260	286									
360	138	165	193	221	248	276										
380	146	175	204	233	262	291										
400	153	184	214	245	276											
425	163	195	228	260	293											
450	172	207	241	276												
475	182	218	255	291												
500	191	230	268													
525	201	241	281													
550	211	253	295													
575	220	264														
600	230	276														

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		60													Figures in body of chart = mm of door opening	
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
20																
30																
40																
50																
60			25	29	34	38	42	46	51	55	59	67	76	84	84	101
70		29	34	39	44	49	54	59	64	69	79	88	98	98	118	118
80	28	34	39	45	51	56	62	67	73	79	90	101	112	112	135	135
90	32	38	44	51	57	63	69	76	82	88	101	114	126	126	152	152
100	35	42	49	56	63	70	77	84	91	98	112	126	140	140	168	168
110	39	46	54	62	69	77	85	93	100	108	124	139	154	154	185	185
120	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	202
130	46	55	64	73	82	91	100	110	119	128	146	164	183	183	219	219
140	49	59	69	79	88	98	108	118	128	138	157	177	197	197	236	236
150	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253	253
160	56	67	79	90	101	112	124	135	146	157	180	202	225	225	270	270
170	60	72	84	95	107	119	131	143	155	167	191	215	239	239	286	286
180	63	76	88	101	114	126	139	152	164	177	202	227	253	253		
190	67	80	93	107	120	133	147	160	173	187	213	240	267	267		
200	70	84	98	112	126	140	154	168	183	197	225	253	281	281		
210	74	88	103	118	133	147	162	177	192	206	236	265	295	295		
220	77	93	108	124	139	154	170	185	201	216	247	278				
230	81	97	113	129	145	161	178	194	210	226	258	291				
240	84	101	118	135	152	168	185	202	219	236	270					
250	88	105	123	140	158	176	193	211	228	246	281					
260	91	110	128	146	164	183	201	219	237	256	292					
270	95	114	133	152	171	190	208	227	246	265						
280	98	118	138	157	177	197	216	236	256	275						
290	102	122	143	163	183	204	224	244	265	285						
300	105	126	147	168	190	211	232	253	274	295						
320	112	135	157	180	202	225	247	270	292							
340	119	143	167	191	215	239	263	286								
360	126	152	177	202	227	253	278									
380	133	160	187	213	240	267	293									
400	140	168	197	225	253	281										
425	149	179	209	239	269	298										
450	158	190	221	253	284											
475	167	200	233	267												
500	176	211	246	281												
525	184	221	258	295												
550	193	232	270													
575	202	242	283													
600	211	253	295													

For Use with [TRANSPREAD](#) Density Meter ..gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		65													Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	
Rate																
20														26	31	
30									25	27	31	35	39	39	47	
40									34	36	41	47	52	52	62	
50				26	29	32	36	39	42	45	52	58	65	65	78	
60			27	31	35	39	43	47	51	54	62	70	78	78	93	
70		27	32	36	41	45	50	54	59	64	73	82	91	91	109	
80	26	31	36	41	47	52	57	62	67	73	83	93	104	104	124	
90	29	35	41	47	52	58	64	70	76	82	93	105	117	117	140	
100	32	39	45	52	58	65	71	78	84	91	104	117	130	130	156	
110	36	43	50	57	64	71	78	86	93	100	114	128	143	143	171	
120	39	47	54	62	70	78	86	93	101	109	124	140	156	156	187	
130	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	
140	45	54	64	73	82	91	100	109	118	127	145	163	181	181	218	
150	49	58	68	78	87	97	107	117	126	136	156	175	194	194	233	
160	52	62	73	83	93	104	114	124	135	145	166	187	207	207	249	
170	55	66	77	88	99	110	121	132	143	154	176	198	220	220	264	
180	58	70	82	93	105	117	128	140	152	163	187	210	233	233	280	
190	62	74	86	98	111	123	135	148	160	172	197	222	246	246	295	
200	65	78	91	104	117	130	143	156	168	181	207	233	259	259		
210	68	82	95	109	122	136	150	163	177	191	218	245	272	272		
220	71	86	100	114	128	143	157	171	185	200	228	257	285	285		
230	75	89	104	119	134	149	164	179	194	209	238	268	298	298		
240	78	93	109	124	140	156	171	187	202	218	249	280				
250	81	97	113	130	146	162	178	194	211	227	259	292				
260	84	101	118	135	152	168	185	202	219	236	270					
270	87	105	122	140	157	175	192	210	227	245	280					
280	91	109	127	145	163	181	200	218	236	254	290					
290	94	113	132	150	169	188	207	226	244	263						
300	97	117	136	156	175	194	214	233	253	272						
320	104	124	145	166	187	207	228	249	270	290						
340	110	132	154	176	198	220	242	264	286							
360	117	140	163	187	210	233	257	280								
380	123	148	172	197	222	246	271	295								
400	130	156	181	207	233	259	285									
425	138	165	193	220	248	275										
450	146	175	204	233	262	292										
475	154	185	215	246	277											
500	162	194	227	259	292											
525	170	204	238	272												
550	178	214	249	285												
575	186	224	261	298												
600	194	233	272													

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		70													Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	
Rate																
20															29	
30														25	29	
40													26	29	31	
50													27	30	33	
60			25	29	32	36	40	43	47	51	58	65	72	72	87	
70		25	29	34	38	42	46	51	55	59	67	76	84	84	101	
80		29	34	39	43	48	53	58	63	67	77	87	96	96	116	
90		32	38	43	49	54	60	65	70	76	87	97	108	108	130	
100	30	36	42	48	54	60	66	72	78	84	96	108	120	120	144	
110	33	40	46	53	60	66	73	79	86	93	106	119	132	132	159	
120	36	43	51	58	65	72	79	87	94	101	116	130	144	144	173	
130	39	47	55	63	70	78	86	94	102	110	125	141	156	156	188	
140	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	
150	45	54	63	72	81	90	99	108	117	126	144	162	181	181	217	
160	48	58	67	77	87	96	106	116	125	135	154	173	193	193	231	
170	51	61	72	82	92	102	113	123	133	143	164	184	205	205	245	
180	54	65	76	87	97	108	119	130	141	152	173	195	217	217	260	
190	57	69	80	91	103	114	126	137	149	160	183	206	229	229	274	
200	60	72	84	96	108	120	132	144	156	168	193	217	241	241	289	
210	63	76	88	101	114	126	139	152	164	177	202	227	253	253		
220	66	79	93	106	119	132	146	159	172	185	212	238	265	265		
230	69	83	97	111	125	138	152	166	180	194	221	249	277	277		
240	72	87	101	116	130	144	159	173	188	202	231	260	289	289		
250	75	90	105	120	135	150	165	181	196	211	241	271				
260	78	94	110	125	141	156	172	188	203	219	250	282				
270	81	97	114	130	146	162	179	195	211	227	260	292				
280	84	101	118	135	152	168	185	202	219	236	270					
290	87	105	122	140	157	174	192	209	227	244	279					
300	90	108	126	144	162	181	199	217	235	253	289					
320	96	116	135	154	173	193	212	231	250	270						
340	102	123	143	164	184	205	225	245	266	286						
360	108	130	152	173	195	217	238	260	282							
380	114	137	160	183	206	229	252	274	297							
400	120	144	168	193	217	241	265	289								
425	128	153	179	205	230	256	281									
450	135	162	190	217	244	271	298									
475	143	171	200	229	257	286										
500	150	181	211	241	271											
525	158	190	221	253	284											
550	165	199	232	265	298											
575	173	208	242	277												
600	181	217	253	289												

For Use with [TRANSPREAD](#) Density Meter ..gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		75													Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	
Rate																
20															27	
30												27	30	34	40	
40								27	29	31	36	40	45	45	54	
50					25	28	31	34	37	39	45	51	56	56	67	
60				27	30	34	37	40	44	47	54	61	67	67	81	
70			28	31	35	39	43	47	51	55	63	71	79	79	94	
80		27	31	36	40	45	49	54	58	63	72	81	90	90	108	
90	25	30	35	40	45	51	56	61	66	71	81	91	101	101	121	
100	28	34	39	45	51	56	62	67	73	79	90	101	112	112	135	
110	31	37	43	49	56	62	68	74	80	86	99	111	124	124	148	
120	34	40	47	54	61	67	74	81	88	94	108	121	135	135	162	
130	37	44	51	58	66	73	80	88	95	102	117	131	146	146	175	
140	39	47	55	63	71	79	86	94	102	110	126	142	157	157	189	
150	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	
160	45	54	63	72	81	90	99	108	117	126	144	162	180	180	216	
170	48	57	67	76	86	95	105	115	124	134	153	172	191	191	229	
180	51	61	71	81	91	101	111	121	131	142	162	182	202	202	243	
190	53	64	75	85	96	107	117	128	139	149	171	192	213	213	256	
200	56	67	79	90	101	112	124	135	146	157	180	202	225	225	270	
210	59	71	83	94	106	118	130	142	153	165	189	212	236	236	283	
220	62	74	86	99	111	124	136	148	161	173	198	222	247	247	297	
230	65	78	90	103	116	129	142	155	168	181	207	233	258	258		
240	67	81	94	108	121	135	148	162	175	189	216	243	270	270		
250	70	84	98	112	126	140	154	168	183	197	225	253	281	281		
260	73	88	102	117	131	146	161	175	190	204	234	263	292	292		
270	76	91	106	121	136	152	167	182	197	212	243	273				
280	79	94	110	126	142	157	173	189	204	220	252	283				
290	81	98	114	130	147	163	179	195	212	228	261	293				
300	84	101	118	135	152	168	185	202	219	236	270					
320	90	108	126	144	162	180	198	216	234	252	288					
340	95	115	134	153	172	191	210	229	248	267						
360	101	121	142	162	182	202	222	243	263	283						
380	107	128	149	171	192	213	235	256	277	299						
400	112	135	157	180	202	225	247	270	292							
425	119	143	167	191	215	239	263	286								
450	126	152	177	202	227	253	278									
475	133	160	187	213	240	267	293									
500	140	168	197	225	253	281										
525	147	177	206	236	265	295										
550	154	185	216	247	278											
575	161	194	226	258	291											
600	168	202	236	270												

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		80													Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	
Rate																
20															25	
30															25	
40														25	28	
50														25	29	
60														25	29	
70														25	29	
80		25	29	34	38	42	46	51	55	59	67	76	84	84	101	
90		28	33	38	43	47	52	57	62	66	76	85	95	95	114	
100	26	32	37	42	47	53	58	63	68	74	84	95	105	105	126	
110	29	35	41	46	52	58	64	69	75	81	93	104	116	116	139	
120	32	38	44	51	57	63	69	76	82	88	101	114	126	126	152	
130	34	41	48	55	62	68	75	82	89	96	110	123	137	137	164	
140	37	44	52	59	66	74	81	88	96	103	118	133	147	147	177	
150	39	47	55	63	71	79	87	95	103	111	126	142	158	158	190	
160	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	
170	45	54	63	72	81	90	98	107	116	125	143	161	179	179	215	
180	47	57	66	76	85	95	104	114	123	133	152	171	190	190	227	
190	50	60	70	80	90	100	110	120	130	140	160	180	200	200	240	
200	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253	
210	55	66	77	88	100	111	122	133	144	155	177	199	221	221	265	
220	58	69	81	93	104	116	127	139	151	162	185	208	232	232	278	
230	61	73	85	97	109	121	133	145	157	170	194	218	242	242	291	
240	63	76	88	101	114	126	139	152	164	177	202	227	253	253		
250	66	79	92	105	118	132	145	158	171	184	211	237	263	263		
260	68	82	96	110	123	137	151	164	178	192	219	246	274	274		
270	71	85	100	114	128	142	156	171	185	199	227	256	284	284		
280	74	88	103	118	133	147	162	177	192	206	236	265	295	295		
290	76	92	107	122	137	153	168	183	198	214	244	275				
300	79	95	111	126	142	158	174	190	205	221	253	284				
320	84	101	118	135	152	168	185	202	219	236	270					
340	90	107	125	143	161	179	197	215	233	251	286					
360	95	114	133	152	171	190	208	227	246	265						
380	100	120	140	160	180	200	220	240	260	280						
400	105	126	147	168	190	211	232	253	274	295						
425	112	134	157	179	201	224	246	269	291							
450	118	142	166	190	213	237	261	284								
475	125	150	175	200	225	250	275									
500	132	158	184	211	237	263	290									
525	138	166	193	221	249	276										
550	145	174	203	232	261	290										
575	151	182	212	242	272											
600	158	190	221	253	284											

For Use with [TRANSPREAD](#) Density Meter ..gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		90													Figures in body of chart = mm of door opening	
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
20																
30																
40																
50																
60																
70																
80																
90																
100																
110	26															
120	28															
130	30															
140	33															
150	35															
160	37															
170	40															
180	42															
190	44															
200	47															
210	49															
220	51															
230	54															
240	56															
250	59															
260	61															
270	63															
280	66															
290	68															
300	70															
320	75															
340	80															
360	84															
380	89															
400	94															
425	99															
450	105															
475	111															
500	117															
525	123															
550	129															
575	135															
600	140															

Gear Box...Low. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		100													Figures in body of chart = mm of door opening	
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
20																
30																
40																
50																
60																
70																
80																
90																
100																
110																
120	25															
130	27															
140	29															
150	32															
160	34															
170	36															
180	38															
190	40															
200	42															
210	44															
220	46															
230	48															
240	51															
250	53															
260	55															
270	57															
280	59															
290	61															
300	63															
320	67															
340	72															
360	76															
380	80															
400	84															
425	90															
450	95															
475	100															
500	105															
525	111															
550	116															
575	121															
600	126															

For Use with **TRANSPREAD** Density Meter .. gb006, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART LB. PER ACRE													
Density Lb. Per Cu Ft.		Figures in body of chart = mm of door opening													
45		gb006, 730													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200	47	56	66	75	84	94	103	112	122	131	150	168	187	225	225
225	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
250	59	70	82	94	105	117	129	140	152	164	187	211	234	234	281
275	64	77	90	103	116	129	142	154	167	180	206	232	257	257	
300	70	84	98	112	126	140	154	168	183	197	225	253	281	281	
325	76	91	106	122	137	152	167	183	198	213	243	274			
350	82	98	115	131	147	164	180	197	213	229	262	295			
375	88	105	123	140	158	176	193	211	228	246	281				
400	94	112	131	150	168	187	206	225	243	262	300				
425	99	119	139	159	179	199	219	239	259	278					
450	105	126	147	168	190	211	232	253	274	295					
475	111	133	156	178	200	222	245	267	289						
500	117	140	164	187	211	234	257	281							
525	123	147	172	197	221	246	270	295							
550	129	154	180	206	232	257	283								
575	135	161	188	215	242	269	296								
600	140	168	197	225	253	281									
625	146	176	205	234	263	293									
650	152	183	213	243	274										
675	158	190	221	253	284										
700	164	197	229	262	295										
750	176	211	246	281											
800	187	225	262	300											
850	199	239	278												
900	211	253	295												
950	222	267													
1000	234	281													
1050	246	295													
1100	257														
1150	269														
1200	281														
1250	293														
1300															
1350															
1400															
1450															
1500															
1550															
1600															
1650															
1700															
1800															

Gear Box...Med. Gear		RATE CHART LB. PER ACRE													
Density Lb. Per Cu Ft.		Figures in body of chart = mm of door opening													
50		gb006, 730													
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
200	42	51	59	67	76	84	93	101	110	118	135	152	168	202	202
225	47	57	66	76	85	95	104	114	123	133	152	171	190	190	227
250	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
275	58	69	81	93	104	116	127	139	151	162	185	208	232	232	278
300	63	76	88	101	114	126	139	152	164	177	202	227	253	253	
325	68	82	96	110	123	137	151	164	178	192	219	246	274	274	
350	74	88	103	118	133	147	162	177	192	206	236	265	295	295	
375	79	95	111	126	142	158	174	190	205	221	253	284			
400	84	101	118	135	152	168	185	202	219	236	270				
425	90	107	125	143	161	179	197	215	233	251	286				
450	95	114	133	152	171	190	208	227	246	265					
475	100	120	140	160	180	200	220	240	260	280					
500	105	126	147	168	190	211	232	253	274	295					
525	111	133	155	177	199	221	243	265	287						
550	116	139	162	185	208	232	255	278							
575	121	145	170	194	218	242	266	291							
600	126	152	177	202	227	253	278								
625	132	158	184	211	237	263	290								
650	137	164	192	219	246	274									
675	142	171	199	227	256	284									
700	147	177	206	236	265	295									
750	158	190	221	253	284										
800	168	202	236	270											
850	179	215	251	286											
900	190	227	265												
950	200	240	280												
1000	211	253	295												
1050	221	265													
1100	232	278													
1150	242	291													
1200	253														
1250	263														
1300	274														
1350	284														
1400	295														
1450															
1500															
1550															
1600															
1650															
1700															
1800															

For Use with [TRANSPREAD](#) Density Meter .. gb006, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear														gb006. 730																	
Density Lb. Per Cu Ft. 55														Density Lb. Per Cu Ft. 60																	
RATE CHART LB. PER ACRE														RATE CHART LB. PER ACRE																	
Figures in body of chart = mm of door opening														Figures in body of chart = mm of door opening																	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																Rate															
200	38	46	54	61	69	77	84	92	100	107	123	138	153	184	184	200	35	42	49	56	63	70	77	84	91	98	112	126	140	168	168
225	43	52	60	69	78	86	95	103	112	121	138	155	172	172	207	225	39	47	55	63	71	79	87	95	103	111	126	142	158	158	190
250	48	57	67	77	86	96	105	115	124	134	153	172	191	191	230	250	44	53	61	70	79	88	97	105	114	123	140	158	176	176	211
275	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253	275	48	58	68	77	87	97	106	116	125	135	154	174	193	193	232
300	57	69	80	92	103	115	126	138	149	161	184	207	230	230	276	300	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
325	62	75	87	100	112	124	137	149	162	174	199	224	249	249	299	325	57	68	80	91	103	114	125	137	148	160	183	205	228	228	274
350	67	80	94	107	121	134	147	161	174	188	214	241	268	268		350	61	74	86	98	111	123	135	147	160	172	197	221	246	246	295
375	72	86	101	115	129	144	158	172	187	201	230	258	287	287		375	66	79	92	105	118	132	145	158	171	184	211	237	263	263	
400	77	92	107	123	138	153	168	184	199	214	245	276				400	70	84	98	112	126	140	154	168	183	197	225	253	281	281	
425	81	98	114	130	146	163	179	195	212	228	260	293				425	75	90	104	119	134	149	164	179	194	209	239	269	298	298	
450	86	103	121	138	155	172	190	207	224	241	276					450	79	95	111	126	142	158	174	190	205	221	253	284			
475	91	109	127	146	164	182	200	218	236	255	291					475	83	100	117	133	150	167	183	200	217	233	267				
500	96	115	134	153	172	191	211	230	249	268						500	88	105	123	140	158	176	193	211	228	246	281				
525	101	121	141	161	181	201	221	241	261	281						525	92	111	129	147	166	184	203	221	240	258	295				
550	105	126	147	168	190	211	232	253	274	295						550	97	116	135	154	174	193	212	232	251	270					
575	110	132	154	176	198	220	242	264	286							575	101	121	141	161	182	202	222	242	262	283					
600	115	138	161	184	207	230	253	276	299							600	105	126	147	168	190	211	232	253	274	295					
625	120	144	168	191	215	239	263	287								625	110	132	154	176	197	219	241	263	285						
650	124	149	174	199	224	249	274	299								650	114	137	160	183	205	228	251	274	297						
675	129	155	181	207	233	258	284									675	118	142	166	190	213	237	261	284							
700	134	161	188	214	241	268	295									700	123	147	172	197	221	246	270	295							
750	144	172	201	230	258	287										750	132	158	184	211	237	263	290								
800	153	184	214	245	276											800	140	168	197	225	253	281									
850	163	195	228	260	293											850	149	179	209	239	269	298									
900	172	207	241	276												900	158	190	221	253	284										
950	182	218	255	291												950	167	200	233	267											
1000	191	230	268													1000	176	211	246	281											
1050	201	241	281													1050	184	221	258	295											
1100	211	253	295													1100	193	232	270												
1150	220	264														1150	202	242	283												
1200	230	276														1200	211	253	295												
1250	239	287														1250	219	263													
1300	249	299														1300	228	274													
1350	258															1350	237	284													
1400	268															1400	246	295													
1450	278															1450	254														
1500	287															1500	263														
1550	297															1550	272														
1600																1600	281														
1650																1650	290														
1700																1700	298														
1800																1800															

For Use with **TRANSPREAD** Density Meter .. gb006, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear														gb006. 730																	
Density Lb. Per Cu Ft. 65														Density Lb. Per Cu Ft. 70																	
RATE CHART LB. PER ACRE														RATE CHART LB. PER ACRE																	
Figures in body of chart = mm or door opening														Figures in body of chart = mm or door opening																	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																Rate															
200	32	39	45	52	58	65	71	78	84	91	104	117	130	156	156	200	30	36	42	48	54	60	66	72	78	84	96	108	120	144	144
225	36	44	51	58	66	73	80	87	95	102	117	131	146	146	175	225	34	41	47	54	61	68	74	81	88	95	108	122	135	135	162
250	40	49	57	65	73	81	89	97	105	113	130	146	162	162	194	250	38	45	53	60	68	75	83	90	98	105	120	135	150	150	181
275	45	53	62	71	80	89	98	107	116	125	143	160	178	178	214	275	41	50	58	66	74	83	91	99	108	116	132	149	165	165	199
300	49	58	68	78	87	97	107	117	126	136	156	175	194	194	233	300	45	54	63	72	81	90	99	108	117	126	144	162	181	181	217
325	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253	325	49	59	68	78	88	98	108	117	127	137	156	176	196	196	235
350	57	68	79	91	102	113	125	136	147	159	181	204	227	227	272	350	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253
375	61	73	85	97	109	121	134	146	158	170	194	219	243	243	292	375	56	68	79	90	102	113	124	135	147	158	181	203	226	226	271
400	65	78	91	104	117	130	143	156	168	181	207	233	259	259		400	60	72	84	96	108	120	132	144	156	168	193	217	241	241	289
425	69	83	96	110	124	138	151	165	179	193	220	248	275	275		425	64	77	90	102	115	128	141	153	166	179	205	230	256	256	
450	73	87	102	117	131	146	160	175	190	204	233	262	292	292		450	68	81	95	108	122	135	149	162	176	190	217	244	271	271	
475	77	92	108	123	139	154	169	185	200	215	246	277				475	71	86	100	114	129	143	157	171	186	200	229	257	286	286	
500	81	97	113	130	146	162	178	194	211	227	259	292				500	75	90	105	120	135	150	165	181	196	211	241	271			
525	85	102	119	136	153	170	187	204	221	238	272					525	79	95	111	126	142	158	174	190	205	221	253	284			
550	89	107	125	143	160	178	196	214	232	249	285					550	83	99	116	132	149	165	182	199	215	232	265	298			
575	93	112	130	149	168	186	205	224	242	261	298					575	86	104	121	138	156	173	190	208	225	242	277				
600	97	117	136	156	175	194	214	233	253	272						600	90	108	126	144	162	181	199	217	235	253	289				
625	101	122	142	162	182	202	223	243	263	284						625	94	113	132	150	169	188	207	226	244	263					
650	105	126	147	168	190	211	232	253	274	295						650	98	117	137	156	176	196	215	235	254	274					
675	109	131	153	175	197	219	241	262	284							675	102	122	142	162	183	203	223	244	264	284					
700	113	136	159	181	204	227	249	272	295							700	105	126	147	168	190	211	232	253	274	295					
750	121	146	170	194	219	243	267	292								750	113	135	158	181	203	226	248	271	293						
800	130	156	181	207	233	259	285									800	120	144	168	193	217	241	265	289							
850	138	165	193	220	248	275										850	128	153	179	205	230	256	281								
900	146	175	204	233	262	292										900	135	162	190	217	244	271	298								
950	154	185	215	246	277											950	143	171	200	229	257	286									
1000	162	194	227	259	292											1000	150	181	211	241	271										
1050	170	204	238	272												1050	158	190	221	253	284										
1100	178	214	249	285												1100	165	199	232	265	298										
1150	186	224	261	298												1150	173	208	242	277											
1200	194	233	272													1200	181	217	253	289											
1250	202	243	284													1250	188	226	263												
1300	211	253	295													1300	196	235	274												
1350	219	262														1350	203	244	284												
1400	227	272														1400	211	253	295												
1450	235	282														1450	218	262													
1500	243	292														1500	226	271													
1550	251															1550	233	280													
1600	259															1600	241	289													
1650	267															1650	248	298													
1700	275															1700	256														
1800	292															1800	271														

For Use with **TRANSPREAD** Density Meter .. gb006, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART LB. PER ACRE													gb006, 730	
Density Lb. Per Cu Ft.		75														
		Figures in body of chart = mm of door opening														
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	
Rate																
200	28	34	39	45	51	56	62	67	73	79	90	101	112	135	135	
225	32	38	44	51	57	63	69	76	82	88	101	114	126	126	152	
250	35	42	49	56	63	70	77	84	91	98	112	126	140	140	168	
275	39	46	54	62	69	77	85	93	100	108	124	139	154	154	185	
300	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	
325	46	55	64	73	82	91	100	110	119	128	146	164	183	183	219	
350	49	59	69	79	88	98	108	118	128	138	157	177	197	197	236	
375	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253	
400	56	67	79	90	101	112	124	135	146	157	180	202	225	225	270	
425	60	72	84	95	107	119	131	143	155	167	191	215	239	239	286	
450	63	76	88	101	114	126	139	152	164	177	202	227	253	253		
475	67	80	93	107	120	133	147	160	173	187	213	240	267	267		
500	70	84	98	112	126	140	154	168	183	197	225	253	281	281		
525	74	88	103	118	133	147	162	177	192	206	236	265	295	295		
550	77	93	108	124	139	154	170	185	201	216	247	278				
575	81	97	113	129	145	161	178	194	210	226	258	291				
600	84	101	118	135	152	168	185	202	219	236	270					
625	88	105	123	140	158	176	193	211	228	246	281					
650	91	110	128	146	164	183	201	219	237	256	292					
675	95	114	133	152	171	190	208	227	246	265						
700	98	118	138	157	177	197	216	236	256	275						
750	105	126	147	168	190	211	232	253	274	295						
800	112	135	157	180	202	225	247	270	292							
850	119	143	167	191	215	239	263	286								
900	126	152	177	202	227	253	278									
950	133	160	187	213	240	267	293									
1000	140	168	197	225	253	281										
1050	147	177	206	236	265	295										
1100	154	185	216	247	278											
1150	161	194	226	258	291											
1200	168	202	236	270												
1250	176	211	246	281												
1300	183	219	256	292												
1350	190	227	265													
1400	197	236	275													
1450	204	244	285													
1500	211	253	295													
1550	218	261														
1600	225	270														
1650	232	278														
1700	239	286														
1800	253															

Gear Box...Med. Gear		RATE CHART LB. PER ACRE													gb006, 730	
Density Lb. Per Cu Ft.		80														
		Figures in body of chart = mm of door opening														
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	
Rate																
200	26	32	37	42	47	53	58	63	68	74	84	95	105	126	126	
225	30	36	41	47	53	59	65	71	77	83	95	107	118	118	142	
250	33	39	46	53	59	66	72	79	86	92	105	118	132	132	158	
275	36	43	51	58	65	72	80	87	94	101	116	130	145	145	174	
300	39	47	55	63	71	79	87	95	103	111	126	142	158	158	190	
325	43	51	60	68	77	86	94	103	111	120	137	154	171	171	205	
350	46	55	64	74	83	92	101	111	120	129	147	166	184	184	221	
375	49	59	69	79	89	99	109	118	128	138	158	178	197	197	237	
400	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253	
425	56	67	78	90	101	112	123	134	145	157	179	201	224	224	269	
450	59	71	83	95	107	118	130	142	154	166	190	213	237	237	284	
475	63	75	88	100	113	125	138	150	163	175	200	225	250	250		
500	66	79	92	105	118	132	145	158	171	184	211	237	263	263		
525	69	83	97	111	124	138	152	166	180	193	221	249	276	276		
550	72	87	101	116	130	145	159	174	188	203	232	261	290	290		
575	76	91	106	121	136	151	167	182	197	212	242	272				
600	79	95	111	126	142	158	174	190	205	221	253	284				
625	82	99	115	132	148	165	181	197	214	230	263	296				
650	86	103	120	137	154	171	188	205	222	240	274					
675	89	107	124	142	160	178	195	213	231	249	284					
700	92	111	129	147	166	184	203	221	240	258	295					
750	99	118	138	158	178	197	217	237	257	276						
800	105	126	147	168	190	211	232	253	274	295						
850	112	134	157	179	201	224	246	269	291							
900	118	142	166	190	213	237	261	284								
950	125	150	175	200	225	250	275									
1000	132	158	184	211	237	263	290									
1050	138	166	193	221	249	276										
1100	145	174	203	232	261	290										
1150	151	182	212	242	272											
1200	158	190	221	253	284											
1250	165	197	230	263	296											
1300	171	205	240	274												
1350	178	213	249	284												
1400	184	221	258	295												
1450	191	229	267													
1500	197	237	276													
1550	204	245	286													
1600	211	253	295													
1650	217	261														
1700	224	269														
1800	237	284														

For Use with **TRANSPREAD** Density Meter .. gb006, 730, Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...Med. Gear		RATE CHART LB. PER ACRE													gb006, 730	
Density Lb. Per Cu Ft.		90														
		Figures in body of chart = mm of door opening														
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
200			28	33	37	42	47	51	56	61	66	75	84	94	112	112
225		26	32	37	42	47	53	58	63	68	74	84	95	105	105	126
250		29	35	41	47	53	59	64	70	76	82	94	105	117	117	140
275		32	39	45	51	58	64	71	77	84	90	103	116	129	129	154
300		35	42	49	56	63	70	77	84	91	98	112	126	140	140	168
325		38	46	53	61	68	76	84	91	99	106	122	137	152	152	183
350		41	49	57	66	74	82	90	98	106	115	131	147	164	164	197
375		44	53	61	70	79	88	97	105	114	123	140	158	176	176	211
400	47	56	66	75	84	94	103	112	122	131	150	168	187	187	225	225
425	50	60	70	80	90	99	109	119	129	139	159	179	199	199	239	239
450	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253	253
475	56	67	78	89	100	111	122	133	144	156	178	200	222	222	267	267
500	59	70	82	94	105	117	129	140	152	164	187	211	234	234	281	281
525	61	74	86	98	111	123	135	147	160	172	197	221	246	246	295	295
550	64	77	90	103	116	129	142	154	167	180	206	232	257	257		
575	67	81	94	108	121	135	148	161	175	188	215	242	269	269		
600	70	84	98	112	126	140	154	168	183	197	225	253	281	281		
625	73	88	102	117	132	146	161	176	190	205	234	263	293	293		
650	76	91	106	122	137	152	167	183	198	213	243	274				
675	79	95	111	126	142	158	174	190	205	221	253	284				
700	82	98	115	131	147	164	180	197	213	229	262	295				
750	88	105	123	140	158	176	193	211	228	246	281					
800	94	112	131	150	168	187	206	225	243	262	300					
850	99	119	139	159	179	199	219	239	259	278						
900	105	126	147	168	190	211	232	253	274	295						
950	111	133	156	178	200	222	245	267	289							
1000	117	140	164	187	211	234	257	281								
1050	123	147	172	197	221	246	270	295								
1100	129	154	180	206	232	257	283									
1150	135	161	188	215	242	269	296									
1200	140	168	197	225	253	281										
1250	146	176	205	234	263	293										
1300	152	183	213	243	274											
1350	158	190	221	253	284											
1400	164	197	229	262	295											
1450	170	204	238	271												
1500	176	211	246	281												
1550	181	218	254	290												
1600	187	225	262	300												
1650	193	232	270													
1700	199	239	278													
1800	211	253	295													

Gear Box...Med. Gear		RATE CHART LB. PER ACRE													gb006, 730	
Density Lb. Per Cu Ft.		100														
		Figures in body of chart = mm of door opening														
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
200			25	29	34	38	42	46	51	55	59	67	76	84	101	101
225			28	33	38	43	47	52	57	62	66	76	85	95	95	114
250		26	32	37	42	47	53	58	63	68	74	84	95	105	105	126
275		29	35	41	46	52	58	64	69	75	81	93	104	116	116	139
300		32	38	44	51	57	63	69	76	82	88	101	114	126	126	152
325		34	41	48	55	62	68	75	82	89	96	110	123	137	137	164
350		37	44	52	59	66	74	81	88	96	103	118	133	147	147	177
375		39	47	55	63	71	79	87	95	103	111	126	142	158	158	190
400	42	51	59	67	76	84	93	101	110	118	135	152	168	168	202	202
425	45	54	63	72	81	90	98	107	116	125	143	161	179	179	215	215
450	47	57	66	76	85	95	104	114	123	133	152	171	190	190	227	227
475	50	60	70	80	90	100	110	120	130	140	160	180	200	200	240	240
500	53	63	74	84	95	105	116	126	137	147	168	190	211	211	253	253
525	55	66	77	88	100	111	122	133	144	155	177	199	221	221	265	265
550	58	69	81	93	104	116	127	139	151	162	185	208	232	232	278	278
575	61	73	85	97	109	121	133	145	157	170	194	218	242	242	291	291
600	63	76	88	101	114	126	139	152	164	177	202	227	253	253		
625	66	79	92	105	118	132	145	158	171	184	211	237	263	263		
650	68	82	96	110	123	137	151	164	178	192	219	246	274	274		
675	71	85	100	114	128	142	156	171	185	199	227	256	284	284		
700	74	88	103	118	133	147	162	177	192	206	236	265	295	295		
750	79	95	111	126	142	158	174	190	205	221	253	284				
800	84	101	118	135	152	168	185	202	219	236	270					
850	90	107	125	143	161	179	197	215	233	251	286					
900	95	114	133	152	171	190	208	227	246	265						
950	100	120	140	160	180	200	220	240	260	280						
1000	105	126	147	168	190	211	232	253	274	295						
1050	111	133	155	177	199	221	243	265	287							
1100	116	139	162	185	208	232	255	278								
1150	121	145	170	194	218	242	266	291								
1200	126	152	177	202	227	253	278									
1250	132	158	184	211	237	263	290									
1300	137	164	192	219	246	274										
1350	142	171	199	227	256	284										
1400	147	177	206	236	265	295										
1450	153	183	214	244	275											
1500	158	190	221	253	284											
1550	163	196	229	261	294											
1600	168	202	236	270												
1650	174	208	243	278												
1700	179	215	251	286												
1800	190	227	265													

For Use with [TRANSPREAD](#) Density Meter .gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		45													Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	
Rate																
500	33	39	46	52	59	66	72	79	85	92	105	118	131	157	170	
525	34	41	48	55	62	69	76	83	89	96	110	124	138	165	179	
550	36	43	50	58	65	72	79	87	94	101	115	130	144	173	187	
575	38	45	53	60	68	75	83	90	98	106	121	136	151	181	196	
600	39	47	55	63	71	79	87	94	102	110	126	142	157	189	204	
625	41	49	57	66	74	82	90	98	107	115	131	147	164	197	213	
650	43	51	60	68	77	85	94	102	111	119	136	153	170	204	222	
675	44	53	62	71	80	88	97	106	115	124	142	159	177	212	230	
700	46	55	64	73	83	92	101	110	119	128	147	165	184	220	239	
750	49	59	69	79	88	98	108	118	128	138	157	177	197	236	256	
800	52	63	73	84	94	105	115	126	136	147	168	189	210	252	273	
850	56	67	78	89	100	111	123	134	145	156	178	201	223	267	290	
900	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307	
950	62	75	87	100	112	125	137	149	162	174	199	224	249	299		
1000	66	79	92	105	118	131	144	157	170	184	210	236	262	315		
1050	69	83	96	110	124	138	151	165	179	193	220	248	275			
1100	72	87	101	115	130	144	159	173	187	202	231	260	288			
1150	75	90	106	121	136	151	166	181	196	211	241	271	301			
1200	79	94	110	126	142	157	173	189	204	220	252	283	315			
1250	82	98	115	131	147	164	180	197	213	229	262	295				
1300	85	102	119	136	153	170	187	204	222	239	273	307				
1350	88	106	124	142	159	177	195	212	230	248	283	319				
1400	92	110	128	147	165	184	202	220	239	257	294					
1450	95	114	133	152	171	190	209	228	247	266	304					
1500	98	118	138	157	177	197	216	236	256	275	315					
1550	102	122	142	163	183	203	223	244	264	284						
1600	105	126	147	168	189	210	231	252	273	294						
1650	108	130	151	173	195	216	238	260	281	303						
1700	111	134	156	178	201	223	245	267	290	312						
1800	118	142	165	189	212	236	260	283	307							
1900	125	149	174	199	224	249	274	299								
2000	131	157	184	210	236	262	288	315								
2500	164	197	229	262	295											
3000	197	236	275	315												
3500	229	275														
4000	262	315														
5000																
6000																
7000																
8000																
9000																
10000																

Gear Box...High. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		50													Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	
Rate																
500	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153	
525	31	37	43	50	56	62	68	74	81	87	99	111	124	149	161	
550	32	39	45	52	58	65	71	78	84	91	104	117	130	156	169	
575	34	41	47	54	61	68	75	81	88	95	109	122	136	163	176	
600	35	42	50	57	64	71	78	85	92	99	113	127	142	170	184	
625	37	44	52	59	66	74	81	88	96	103	118	133	147	177	192	
650	38	46	54	61	69	77	84	92	100	107	123	138	153	184	199	
675	40	48	56	64	72	80	88	96	104	111	127	143	159	191	207	
700	41	50	58	66	74	83	91	99	107	116	132	149	165	198	215	
750	44	53	62	71	80	88	97	106	115	124	142	159	177	212	230	
800	47	57	66	76	85	94	104	113	123	132	151	170	189	227	245	
850	50	60	70	80	90	100	110	120	130	140	160	181	201	241	261	
900	53	64	74	85	96	106	117	127	138	149	170	191	212	255	276	
950	56	67	78	90	101	112	123	134	146	157	179	202	224	269	291	
1000	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307	
1050	62	74	87	99	111	124	136	149	161	173	198	223	248	297		
1100	65	78	91	104	117	130	143	156	169	182	208	234	260	311		
1150	68	81	95	109	122	136	149	163	176	190	217	244	271			
1200	71	85	99	113	127	142	156	170	184	198	227	255	283			
1250	74	88	103	118	133	147	162	177	192	206	236	265	295			
1300	77	92	107	123	138	153	169	184	199	215	245	276	307			
1350	80	96	111	127	143	159	175	191	207	223	255	287	319			
1400	83	99	116	132	149	165	182	198	215	231	264	297				
1450	86	103	120	137	154	171	188	205	222	239	274	308				
1500	88	106	124	142	159	177	195	212	230	248	283	319				
1550	91	110	128	146	165	183	201	219	238	256	293					
1600	94	113	132	151	170	189	208	227	245	264	302					
1650	97	117	136	156	175	195	214	234	253	273	311					
1700	100	120	140	160	181	201	221	241	261	281						
1800	106	127	149	170	191	212	234	255	276	297						
1900	112	134	157	179	202	224	247	269	291	314						
2000	118	142	165	189	212	236	260	283	307							
2500	147	177	206	236	265	295										
3000	177	212	248	283	319											
3500	206	248	289													
4000	236	283														
5000	295															
6000																
7000																
8000																
9000																
10000																

For Use with [TRANSPREAD](#) Density Meter .gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb006. 730	
Density Lb. Per Cu Ft.		55												Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
500	27	32	38	43	48	54	59	64	70	75	86	97	107	129	139
525	28	34	39	45	51	56	62	68	73	79	90	101	113	135	146
550	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153
575	31	37	43	49	56	62	68	74	80	86	99	111	123	148	160
600	32	39	45	51	58	64	71	77	84	90	103	116	129	154	167
625	34	40	47	54	60	67	74	80	87	94	107	121	134	161	174
650	35	42	49	56	63	70	77	84	91	98	112	125	139	167	181
675	36	43	51	58	65	72	80	87	94	101	116	130	145	174	188
700	38	45	53	60	68	75	83	90	98	105	120	135	150	180	195
750	40	48	56	64	72	80	88	97	105	113	129	145	161	193	209
800	43	51	60	69	77	86	94	103	112	120	137	154	172	206	223
850	46	55	64	73	82	91	100	109	119	128	146	164	182	219	237
900	48	58	68	77	87	97	106	116	125	135	154	174	193	232	251
950	51	61	71	82	92	102	112	122	132	143	163	183	204	245	265
1000	54	64	75	86	97	107	118	129	139	150	172	193	215	257	279
1050	56	68	79	90	101	113	124	135	146	158	180	203	225	270	293
1100	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307
1150	62	74	86	99	111	123	136	148	160	173	197	222	247	296	
1200	64	77	90	103	116	129	142	154	167	180	206	232	257	309	
1250	67	80	94	107	121	134	147	161	174	188	215	241	268		
1300	70	84	98	112	125	139	153	167	181	195	223	251	279		
1350	72	87	101	116	130	145	159	174	188	203	232	261	290		
1400	75	90	105	120	135	150	165	180	195	210	240	270	300		
1450	78	93	109	124	140	156	171	187	202	218	249	280	311		
1500	80	97	113	129	145	161	177	193	209	225	257	290			
1550	83	100	116	133	150	166	183	199	216	233	266	299			
1600	86	103	120	137	154	172	189	206	223	240	275	309			
1650	88	106	124	142	159	177	195	212	230	248	283	319			
1700	91	109	128	146	164	182	201	219	237	255	292				
1800	97	116	135	154	174	193	212	232	251	270	309				
1900	102	122	143	163	183	204	224	245	265	285					
2000	107	129	150	172	193	215	236	257	279	300					
2500	134	161	188	215	241	268	295								
3000	161	193	225	257	290										
3500	188	225	263	300											
4000	215	257	300												
5000	268														
6000															
7000															
8000															
9000															
10000															

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb006. 730	
Density Lb. Per Cu Ft.		60												Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate															
500	29	34	39	44	49	54	59	64	69	79	88	98	108	118	128
525	26	31	36	41	46	52	57	62	67	72	83	93	103	113	124
550	27	32	38	43	49	54	59	65	70	76	87	97	108	118	130
575	28	34	40	45	51	57	62	68	73	79	90	102	113	123	136
600	29	35	41	47	53	59	65	71	77	83	94	106	118	128	142
625	31	37	43	49	55	61	68	74	80	86	98	111	123	133	147
650	32	38	45	51	58	64	70	77	83	89	102	115	128	138	153
675	33	40	46	53	60	66	73	80	86	93	106	119	133	143	159
700	34	41	48	55	62	69	76	83	89	96	110	124	138	148	165
750	37	44	52	59	66	74	81	88	96	103	118	133	147	157	177
800	39	47	55	63	71	79	87	94	102	110	126	142	157	167	189
850	42	50	58	67	75	84	92	100	109	117	134	150	167	177	201
900	44	53	62	71	80	88	97	106	115	124	142	159	177	187	212
950	47	56	65	75	84	93	103	112	121	131	149	168	187	197	224
1000	49	59	69	79	88	98	108	118	128	138	157	177	197	207	236
1050	52	62	72	83	93	103	114	124	134	145	165	186	206	216	248
1100	54	65	76	87	97	108	119	130	141	151	173	195	216	226	260
1150	57	68	79	90	102	113	124	136	147	158	181	204	226	236	271
1200	59	71	83	94	106	118	130	142	153	165	189	212	236	246	283
1250	61	74	86	98	111	123	135	147	160	172	197	221	246	256	295
1300	64	77	89	102	115	128	141	153	166	179	204	230	256	266	307
1350	66	80	93	106	119	133	146	159	173	186	212	239	265	275	319
1400	69	83	96	110	124	138	151	165	179	193	220	248	275		
1450	71	86	100	114	128	143	157	171	185	200	228	257	285		
1500	74	88	103	118	133	147	162	177	192	206	236	265	295		
1550	76	91	107	122	137	152	168	183	198	213	244	274	305		
1600	79	94	110	126	142	157	173	189	204	220	252	283	315		
1650	81	97	114	130	146	162	178	195	211	227	260	292			
1700	84	100	117	134	150	167	184	201	217	234	267	301			
1800	88	106	124	142	159	177	195	212	230	248	283	319			
1900	93	112	131	149	168	187	205	224	243	262	299				
2000	98	118	138	157	177	197	216	236	256	275	315				
2500	123	147	172	197	221	246	270	295	320						
3000	147	177	206	236	265	295									
3500	172	206	241	275	310										
4000	197	236	275	315											
5000	246	295													
6000	295														
7000															
8000															
9000															
10000															

For Use with [TRANSPREAD](#) Density Meter .gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb006. 730		
Density Lb. Per Cu Ft.		65												Figures in body of chart = mm of door opening		
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
500			27	32	36	41	45	50	54	59	64	73	82	91	109	118
525			29	33	38	43	48	52	57	62	67	76	86	95	114	124
550			30	35	40	45	50	55	60	65	70	80	90	100	120	130
575	26		31	37	42	47	52	57	63	68	73	83	94	104	125	136
600	27		33	38	44	49	54	60	65	71	76	87	98	109	131	142
625	28		34	40	45	51	57	62	68	74	79	91	102	113	136	147
650	29		35	41	47	53	59	65	71	77	83	94	106	118	142	153
675	31		37	43	49	55	61	67	74	80	86	98	110	123	147	159
700	32		38	44	51	57	64	70	76	83	89	102	114	127	152	165
750	34		41	48	54	61	68	75	82	88	95	109	123	136	163	177
800	36		44	51	58	65	73	80	87	94	102	116	131	145	174	189
850	39		46	54	62	69	77	85	93	100	108	123	139	154	185	201
900	41		49	57	65	74	82	90	98	106	114	131	147	163	196	212
950	43		52	60	69	78	86	95	103	112	121	138	155	172	207	224
1000	45		54	64	73	82	91	100	109	118	127	145	163	182	218	236
1050	48		57	67	76	86	95	105	114	124	133	152	172	191	229	248
1100	50		60	70	80	90	100	110	120	130	140	160	180	200	240	260
1150	52		63	73	83	94	104	115	125	136	146	167	188	209	250	271
1200	54		65	76	87	98	109	120	131	142	152	174	196	218	261	283
1250	57		68	79	91	102	113	125	136	147	159	182	204	227	272	295
1300	59		71	83	94	106	118	130	142	153	165	189	212	236	283	307
1350	61		74	86	98	110	123	135	147	159	172	196	221	245	294	319
1400	64		76	89	102	114	127	140	152	165	178	203	229	254	305	
1450	66		79	92	105	118	132	145	158	171	184	211	237	263	316	
1500	68		82	95	109	123	136	150	163	177	191	218	245	272		
1550	70		84	98	113	127	141	155	169	183	197	225	253	281		
1600	73		87	102	116	131	145	160	174	189	203	232	261	290		
1650	75		90	105	120	135	150	165	180	195	210	240	270	299		
1700	77		93	108	123	139	154	170	185	201	216	247	278	309		
1800	82		98	114	131	147	163	180	196	212	229	261	294			
1900	86		103	121	138	155	172	190	207	224	241	276	310			
2000	91		109	127	145	163	182	200	218	236	254	290				
2500	113		136	159	182	204	227	250	272	295	318					
3000	136		163	191	218	245	272	299								
3500	159		191	222	254	286	318									
4000	182		218	254	290											
5000	227		272	318												
6000	272															
7000	318															
8000																
9000																
10000																

Gear Box...High. Gear		RATE CHART LB. PER ACRE												gb006. 730		
Density Lb. Per Cu Ft.		70												Figures in body of chart = mm of door opening		
Width.		25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
Rate																
500			25	29	34	38	42	46	51	55	59	67	76	84	101	110
525			27	31	35	40	44	49	53	58	62	71	80	88	106	115
550			28	32	37	42	46	51	56	60	65	74	83	93	111	121
575	26		29	34	39	44	48	53	58	63	68	78	87	97	116	126
600	27		30	35	40	46	51	56	61	66	71	81	91	101	121	131
625	28		32	37	42	47	53	58	63	68	74	84	95	105	126	137
650	29		33	38	44	49	55	60	66	71	77	88	99	110	131	142
675	31		34	40	46	51	57	63	68	74	80	91	102	114	137	148
700	32		35	41	47	53	59	65	71	77	83	94	106	118	142	153
750	34		38	44	51	57	63	70	76	82	88	101	114	126	152	164
800	36		40	47	54	61	67	74	81	88	94	108	121	135	162	175
850	39		43	50	57	64	72	79	86	93	100	115	129	143	172	186
900	41		46	53	61	68	76	83	91	99	106	121	137	152	182	197
950	43		48	56	64	72	80	88	96	104	112	128	144	160	192	208
1000	45		51	59	67	76	84	93	101	110	118	135	152	169	202	219
1050	48		53	62	71	80	88	97	106	115	124	142	159	177	212	230
1100	50		56	65	74	83	93	102	111	121	130	148	167	185	222	241
1150	52		58	68	78	87	97	107	116	126	136	155	174	194	233	252
1200	54		61	71	81	91	101	111	121	131	142	162	182	202	243	263
1250	57		63	74	84	95	105	116	126	137	147	169	190	211	253	274
1300	59		66	77	88	99	110	121	131	142	153	175	197	219	263	285
1350	61		68	80	91	102	114	125	137	148	159	182	205	228	273	296
1400	64		71	83	94	106	118	130	142	153	165	189	212	236	283	307
1450	66		73	86	98	110	122	134	147	159	171	196	220	244	293	318
1500	68		76	88	101	114	126	139	152	164	177	202	228	253	303	
1550	70		78	91	104	118	131	144	157	170	183	209	235	261	313	
1600	73		81	94	108	121	135	148	162	175	189	216	243	270		
1650	75		83	97	111	125	139	153	167	181	195	222	250	278		
1700	77		86	100	115	129	143	158	172	186	201	229	258	287		
1800	82		91	106	121	137	152	167	182	197	212	243	273	303		
1900	86		96	112	128	144	160	176	192	208	224	256	288			
2000	91		101	118	135	152	169	185	202	219	236	270	303			
2500	113		126	147	169	190	211	232	253	274	295					
3000	126		152	177	202	228	253	278	303							
3500	147		177	206	236	265	295									
4000	169		202	236	270	303										
5000	211		253	295												
6000	253		303													
7000	295															
8000																
9000																
10000																

For Use with [TRANSPREAD](#) Density Meter .gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		75													Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	Rate
500				28	31	35	39	43	47	51	55	63	71	79	94	102
525				29	33	37	41	45	50	54	58	66	74	83	99	107
550		26		30	35	39	43	48	52	56	61	69	78	87	104	112
575		27		32	36	41	45	50	54	59	63	72	81	90	109	118
600		28		33	38	42	47	52	57	61	66	76	85	94	113	123
625		29		34	39	44	49	54	59	64	69	79	88	98	118	128
650	26	31	36	41	46	51	56	61	66	72	82	92	102	123	133	
675	27	32	37	42	48	53	58	64	69	74	85	96	106	127	138	
700	28	33	39	44	50	55	61	66	72	77	88	99	110	132	143	
750	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153	
800	31	38	44	50	57	63	69	76	82	88	101	113	126	151	164	
850	33	40	47	53	60	67	74	80	87	94	107	120	134	160	174	
900	35	42	50	57	64	71	78	85	92	99	113	127	142	170	184	
950	37	45	52	60	67	75	82	90	97	105	120	134	149	179	194	
1000	39	47	55	63	71	79	87	94	102	110	126	142	157	189	204	
1050	41	50	58	66	74	83	91	99	107	116	132	149	165	198	215	
1100	43	52	61	69	78	87	95	104	112	121	138	156	173	208	225	
1150	45	54	63	72	81	90	99	109	118	127	145	163	181	217	235	
1200	47	57	66	76	85	94	104	113	123	132	151	170	189	227	245	
1250	49	59	69	79	88	98	108	118	128	138	157	177	197	236	256	
1300	51	61	72	82	92	102	112	123	133	143	164	184	204	245	266	
1350	53	64	74	85	96	106	117	127	138	149	170	191	212	255	276	
1400	55	66	77	88	99	110	121	132	143	154	176	198	220	264	286	
1450	57	68	80	91	103	114	125	137	148	160	182	205	228	274	297	
1500	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307	
1550	61	73	85	98	110	122	134	146	158	171	195	219	244	293	317	
1600	63	76	88	101	113	126	138	151	164	176	201	227	252	302		
1650	65	78	91	104	117	130	143	156	169	182	208	234	260	311		
1700	67	80	94	107	120	134	147	160	174	187	214	241	267			
1800	71	85	99	113	127	142	156	170	184	198	227	255	283			
1900	75	90	105	120	134	149	164	179	194	209	239	269	299			
2000	79	94	110	126	142	157	173	189	204	220	252	283	315			
2500	98	118	138	157	177	197	216	236	256	275	315					
3000	118	142	165	189	212	236	260	283	307							
3500	138	165	193	220	248	275	303									
4000	157	189	220	252	283	315										
5000	197	236	275	315												
6000	236	283														
7000	275															
8000	315															
9000																
10000																

Gear Box...High. Gear		RATE CHART LB. PER ACRE													gb006. 730	
Density Lb. Per Cu Ft.		80													Figures in body of chart = mm of door opening	
Width.	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130	Rate
500				26	29	33	37	41	44	48	52	59	66	74	88	96
525				27	31	35	39	43	46	50	54	62	70	77	93	101
550				28	32	36	41	45	49	53	57	65	73	81	97	105
575		25		30	34	38	42	47	51	55	59	68	76	85	102	110
600		27		31	35	40	44	49	53	58	62	71	80	88	106	115
625		28		32	37	41	46	51	55	60	65	74	83	92	111	120
650		29	34	38	43	48	53	58	62	67	77	86	96	115	125	
675		30	35	40	45	50	55	60	65	70	80	90	100	119	129	
700	26	31	36	41	46	52	57	62	67	72	83	93	103	124	134	
750	28	33	39	44	50	55	61	66	72	77	88	100	111	133	144	
800	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153	
850	31	38	44	50	56	63	69	75	81	88	100	113	125	150	163	
900	33	40	46	53	60	66	73	80	86	93	106	119	133	159	173	
950	35	42	49	56	63	70	77	84	91	98	112	126	140	168	182	
1000	37	44	52	59	66	74	81	88	96	103	118	133	147	177	192	
1050	39	46	54	62	70	77	85	93	101	108	124	139	155	186	201	
1100	41	49	57	65	73	81	89	97	105	114	130	146	162	195	211	
1150	42	51	59	68	76	85	93	102	110	119	136	153	170	204	220	
1200	44	53	62	71	80	88	97	106	115	124	142	159	177	212	230	
1250	46	55	65	74	83	92	101	111	120	129	147	166	184	221	240	
1300	48	58	67	77	86	96	105	115	125	134	153	173	192	230	249	
1350	50	60	70	80	90	100	109	119	129	139	159	179	199	239	259	
1400	52	62	72	83	93	103	114	124	134	145	165	186	206	248	268	
1450	53	64	75	86	96	107	118	128	139	150	171	192	214	257	278	
1500	55	66	77	88	100	111	122	133	144	155	177	199	221	265	288	
1550	57	69	80	91	103	114	126	137	149	160	183	206	229	274	297	
1600	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307	
1650	61	73	85	97	109	122	134	146	158	170	195	219	243	292	316	
1700	63	75	88	100	113	125	138	150	163	175	201	226	251	301		
1800	66	80	93	106	119	133	146	159	173	186	212	239	265	319		
1900	70	84	98	112	126	140	154	168	182	196	224	252	280			
2000	74	88	103	118	133	147	162	177	192	206	236	265	295			
2500	92	111	129	147	166	184	203	221	240	258	295					
3000	111	133	155	177	199	221	243	265	288	310						
3500	129	155	181	206	232	258	284	310								
4000	147	177	206	236	265	295										
5000	184	221	258	295												
6000	221	265	310													
7000	258	310														
8000	295															
9000																
10000																

For Use with [TRANSPREAD](#) Density Meter ..gb006, 730 Standard Jockey. Accuracy of final settings operators responsibility based on use
 ... Other rates and rate calculator can be viewed at www.transpread.com/spreaders/trailers, also available in XL format for your own computer.

Gear Box...High. Gear		RATE CHART LB. PER ACRE													gb006, 730	
Density Lb. Per Cu Ft.		90													Figures in body of chart = mm of door opening	
Width.	Rate	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130
500					26	29	33	36	39	43	46	52	59	66	79	85
525					28	31	34	38	41	45	48	55	62	69	83	89
550			25		29	32	36	40	43	47	50	58	65	72	87	94
575			26		30	34	38	41	45	49	53	60	68	75	90	98
600			28		31	35	39	43	47	51	55	63	71	79	94	102
625			29		33	37	41	45	49	53	57	66	74	82	98	107
650		26	30	34	38	43	47	51	55	60	68	77	85	102	111	
675		27	31	35	40	44	49	53	58	62	71	80	88	106	115	
700		28	32	37	41	46	50	55	60	64	73	83	92	110	119	
750		29	34	39	44	49	54	59	64	69	79	88	98	118	128	
800	26	31	37	42	47	52	58	63	68	73	84	94	105	126	136	
850	28	33	39	45	50	56	61	67	72	78	89	100	111	134	145	
900	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153	
950	31	37	44	50	56	62	68	75	81	87	100	112	125	149	162	
1000	33	39	46	52	59	66	72	79	85	92	105	118	131	157	170	
1050	34	41	48	55	62	69	76	83	89	96	110	124	138	165	179	
1100	36	43	50	58	65	72	79	87	94	101	115	130	144	173	187	
1150	38	45	53	60	68	75	83	90	98	106	121	136	151	181	196	
1200	39	47	55	63	71	79	87	94	102	110	126	142	157	189	204	
1250	41	49	57	66	74	82	90	98	107	115	131	147	164	197	213	
1300	43	51	60	68	77	85	94	102	111	119	136	153	170	204	222	
1350	44	53	62	71	80	88	97	106	115	124	142	159	177	212	230	
1400	46	55	64	73	83	92	101	110	119	128	147	165	184	220	239	
1450	48	57	67	76	86	95	105	114	124	133	152	171	190	228	247	
1500	49	59	69	79	88	98	108	118	128	138	157	177	197	236	256	
1550	51	61	71	81	91	102	112	122	132	142	163	183	203	244	264	
1600	52	63	73	84	94	105	115	126	136	147	168	189	210	252	273	
1650	54	65	76	87	97	108	119	130	141	151	173	195	216	260	281	
1700	56	67	78	89	100	111	123	134	145	156	178	201	223	267	290	
1800	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307	
1900	62	75	87	100	112	125	137	149	162	174	199	224	249	299		
2000	66	79	92	105	118	131	144	157	170	184	210	236	262	315		
2500	82	98	115	131	147	164	180	197	213	229	262	295				
3000	98	118	138	157	177	197	216	236	256	275	315					
3500	115	138	161	184	206	229	252	275	298							
4000	131	157	184	210	236	262	288	315								
5000	164	197	229	262	295											
6000	197	236	275	315												
7000	229	275														
8000	262	315														
9000	295															
10000																

Gear Box...High. Gear		RATE CHART LB. PER ACRE													gb006, 730								
Density Lb. Per Cu Ft.		100													Figures in body of chart = mm of door opening								
Width.	Rate	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130							
500												27	29	32	35	38	41	47	53	59	71	77	
525												28	31	34	37	40	43	50	56	62	74	81	
550												26	29	32	36	39	42	45	52	58	65	78	84
575												27	31	34	37	41	44	47	54	61	68	81	88
600												28	32	35	39	42	46	50	57	64	71	85	92
625												29	33	37	41	44	48	52	59	66	74	88	96
650			26	31	35	38	42	46	50	54	60	68	77	85	102	111							
675			27	32	36	40	44	48	52	56	62	71	80	88	106	115							
700			28	33	37	41	45	50	54	58	64	73	83	92	110	119							
750			29	34	39	44	49	53	58	62	69	79	88	98	118	128							
800		27	31	35	40	44	49	53	58	62	71	80	88	98	118	128							
850		28	32	36	40	44	49	53	58	62	71	80	88	98	118	128							
900	25	30	35	40	45	50	55	60	65	70	80	90	100	120	130								
950	27	32	37	42	48	53	58	64	69	74	85	96	106	127	138								
1000	28	34	39	45	50	56	62	67	73	78	90	101	112	134	146								
1050	29	35	41	47	53	59	65	71	77	83	94	106	118	142	153								
1100	31	37	43	50	56	62	68	74	81	87	99	111	124	149	161								
1150	32	39	45	52	58	65	71	78	84	91	104	117	130	156	169								
1200	34	41	47	54	61	68	75	81	88	95	109	122	136	163	176								
1250	35	42	50	57	64	71	78	85	92	99	113	127	142	170	184								
1300	37	44	52	59	66	74	81	88	96	103	118	133	147	177	192								
1350	38	46	54	61	69	77	84	92	100	107	123	138	153	184	199								
1400	40	48	56	64	72	80	88	96	104	111	127	143	159	191	207								
1450	41	50	58	66	74	83	91	99	107	116	132	149	165	198	215								
1500	43	51	60	68	77	86	94	103	111	120	137	154	171	205	222								
1550	44	53	62	71	80	88	97	106	115	124	142	159	177	212	230								
1600	46	55	64	73	82	91	101	110	119	128	146	165	183	219	238								
1650	47	57	66	76	85	94	104	113	123	132	151	170	189	227	245								
1700	49	58	68	78	88	97	107	117	127	136	156	175	195	234	253								
1750	50	60	70	80	90	100	110	120	130	140	160	181	201	241	261								
1800	53	64	74	85	96	106	117	127	138	149	170	191	212	255	276								
1900	56	67	78	90	101	112	123	134	146	157	179	202	224	269	291								
2000	59	71	83	94	106	118	130	142	153	165	189	212	236	283	307								
2500	74	88	103	118	133	147	162	177	192	206	236	265	295										
3000	88	106	124	142	159	177	195	212	230	248	283	319											
3500	103	124	145	165	186	206	227	248	268	289													
4000	118	142	165	189	212	236	260	283	307														
5000	147	177	206	236	265	295																	
6000	177	212	248	283	319																		
7000	206	248	289																				
8000	236	283																					
9000	265	319																					
10000	295																						